

# Uf 811

(full pipe)

User manual



## Ultraflux

Bâtiment Texas – Éragny Parc  
9, Allée Rosa Luxemburg  
95610 ÉRAGNY SUR OISE, FRANCE  
Tel.: 33 (0)1 30 27 27 30  
Fax: 33 (0)1 30 39 84 34

2012 ULTRAFLUX S.A.

All rights reserved. No part of this document may be reproduced without prior written authorisation from ULTRAFLUX S.A. ULTRAFLUX, Uf 811 are registered trademarks of ULTRAFLUX S.A.

# TABLE OF CONTENTS<sup>1</sup>

**Important:** If you are unfamiliar with the transit time difference measuring technique, we recommend you start by reading our training manual, "Ultrasonic transit time flowmeter".

<b>CHAPTER 1: OVERVIEW</b>	<b>4</b>
1.1 Converter overview	5
1.2 Dimensions and weight	5
1.3 Working environment	5
1.4 Protection against dust and immersion	5
1.5 Power supply	6
1.6 Communication	6
1.7 Inputs/Outputs	7
1.8 Ultrasound chords	7
1.9 Navigation keys	7
1.10 Operating lamps	8
1.11 Screen	8
1.12 Functions	9
1.13 Performance of the flow meter	9
1.14 Cleaning the flow meter	9
1.15 Recycling the flow meter	9
1.16 CE marking	10
<b>CHAPTER 2: SAFETY INSTRUCTIONS</b>	<b>11</b>
2.1 Using the flow meter	12
2.2 Symbols used on the flow meter	12
2.3 Contact address	13
<b>CHAPTER 3: INSTALLATION AND WIRING</b>	<b>14</b>
3.1 Wall attachment	15
3.2 Wiring instructions	16
3.3 Connector wiring	16
3.4 Ground connection	27
3.5 Connection	27
<b>CHAPTER 4: INSTALLING A MEASURING POINT</b>	<b>28</b>
4.1 Composition of a measuring point	29
4.2 Choosing the measurement location	29
4.3 Choosing the probe location	32
4.4 Installing probes and connectors	35

---

<sup>1</sup> A detailed table of contents is provided at the end of the manual.

<b>CHAPTER 5: USING AND CONFIGURING THE Uf 811</b>	<b>38</b>
5.1 Using the Uf 811	39
5.2 Main configuration elements	40
5.3 Configuring the Uf 811	40
5.4 SIMPLE configuration	42
5.5 NORMAL configuration	54
5.6 ADVANCED configuration	58
5.7 "Measurement" mode	62
<b>CHAPTER 6: FUNCTION ENGINE</b>	<b>65</b>
6.1 Principle	66
6.2 Application examples	66
<b>CHAPTER 7: PC SOFTWARE</b>	<b>67</b>
7.1 Introduction	68
7.2 Archiving, processing and printing of saved files	80
7.3 Settings files	80
<b>Appendix I: Characteristic echo signals</b>	<b>81</b>
<b>Appendix II: Speed of sound in water</b>	<b>84</b>
<b>Appendix III Troubleshooting</b>	<b>86</b>
III.1 Diagnostic indications	87
III.2 Description of fault bits	89
III.3 Fault grid	92
<b>Appendix IV: Link protocol of the Uf 811</b>	<b>93</b>
IV.1 Serial link characteristics	94
IV.2 Reading of N words (with $N \leq 125$ )	95
IV.3 Modbus / Jbus table	96
IV.4 CRC16 calculation algorithm	100

# **CHAPTER 1: OVERVIEW**

## 1.1 Converter overview



## 1.2 Dimensions and weight

- Height: 231 mm
- Width: 221 mm
- Depth: 59 mm
- Weight: 2 Kg

## 1.3 Working environment

- Temperature: from -20 to +70°C
- Hygrometry: 80 % maximum
- Screen reading: from -20°C to +60°C
- Ventilation: no special precautions necessary

## 1.4 Protection against dust and immersion

**IP 67:** Total protection against dust; protection against immersion for 30 minutes under 1m of water. This protection is only valid if the installation has been carried out or audited by Ultraflux.

This protection is only ensured when the connectors are connected or capped (where the connector is not in use).

## 1.5 Power supply

- Range: 10–32 VDC (SELV networks)
- Peak power consumption: < 12 W
- Protection via resettable fuse (PTC)
- Overvoltage protection in accordance with standard EN 61000-4-5
- Insulation: Safety class 3
- Average typical consumption: < 6 W
- Protection against polarity reversal

### Notes:

- As the device is supplied from a protected extra low voltage network, an earth connection is not mandatory. Nevertheless, it is strongly recommended to install an earth connection in order to protect the installation, particularly when used outside with a long length of cable connected to the device. The earth can be connected to the power socket or via one screw.
- It is recommended to install a disconnectable bipolar circuit breaker interrupter with visible cut-off of 2 A upstream of the flow meter power supply. It is also recommended to install lightning arresters on each of the inputs/outputs of the flow meter.

### Important:

- The connectors must only be connected or disconnected with the power off and the equipment isolated.
- If the flow meter unit is opened by anyone other than an Ultraflux technician, the warranty will be rendered null and void.
- Ultraflux accepts no responsibility for incidents which may occur following a failure to respect these instructions.

## 1.6 Communication

The Uf 811 has a serial link which can be wired using **RS232** or **RS485** mode. It also has a USB interface.

For this communication interface, the standard protocol chosen is the Slave JBUS (MODBUS). This enables the device to be connected to an instrumentation and control system or to a computer. Ultraflux provides PC software compatible with Windows XP or later which is used to configure the device, unload the logger and display the various values measured.

Please refer to the appendices for the JBUS configuration.

### Note:

- If necessary, the 120 Ohm termination resistance for the RS485 may be added in the connector between the Y and Z pins.
- The USB interface allows a computer to be connected for configuration. This may be accessed by removing the IP protective cap.

## 1.7 Inputs/Outputs

The Uf 811 provides the following options:

- Integration of up to 4 single modules (or 2 double modules) of inputs/outputs.
- Connection of the inputs/outputs to the equipment directly via connectors, without the need for any intervention inside the flow meter.

The modules are factory-installed by Ultraflux.

The Uf 811 allows six types of inputs/outputs to be used:

- Single module 1 active 4-20 mA insulated analogue output: current from 0 to 24 mA,
- Single module 2 passive 4-20 mA insulated analogue inputs: current from 0 to 24 mA,
- Single module 2 passive 0-10 V insulated analogue inputs: voltage from 0 to 15 V,
- Single module 2 on/off outputs (50 V - 10 mA) which can be used as frequency outputs,
- Single module 2 on/off inputs (5 V),
- Double module 2 PT100/PT1000 temperature inputs; 2- 3- or 4-wire.

### Notes:

- Please refer to the descriptive sheet for each module for more details.
- The sensors on the 4-20 mA loop may be powered from an external power supply.

## 1.8 Ultrasound chords

The Uf 811 can manage 2 ultrasound chords. Each connector corresponds to one ultrasonic chord, in other words two probes. As standard, it is therefore necessary to use the Y-cable provided with the flow meter in order to separate the two probe cables.

## 1.9 Navigation keys

- Changing from one type of screen to another is done by using the "Fn" (for Function) key. This "Fn" key in particular is used to enter "configuration" mode. The ◀ and ▶ keys allow the user to browse through the menus for this mode.
- A long press on the Fn key, or allowing approximately 1 minute to pass without using the keypad, returns you to "measurement" mode.
- Within a menu, the ◀ and ▶ keys are used to change page. These keys may also have a contextual function which in this case will be shown at the bottom of the screen page, such as that of selecting the measurement mode screen which is displayed by default.
- After powering on the Uf 811, the screen displays the page which has been selected as priority. To choose this "default" screen, select and validate it by pressing the "B" key in measurement mode.
- To scroll through the measurement screens, use the ▲ and ▼ keys.
- To access the other menus, press the "Fn" key, then successively press the ◀ key, or browse using the ◀ and ▶ keys.

- To enter a menu, press ▲ or ▼.
- To change page, press "A" or "B".
- To change a row, select it using ▲ or ▼ and change the value using ◀ or ▶.
- If no key is pressed for approximately one minute, the Uf 811 automatically returns to "measurement" mode and to the display chosen as priority using "B".
- For a given parameter, the value to be applied is defined using the ▶ (increase) and ◀ (decrease) keys. An extended press on one of these two keys accelerates the increase or the decrease.


## 1.10 Operating lamps

Two LEDs are present on the front panel:

- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>• <b>Blue measurement LED:</b> indicates whether or not the flow meter is measuring.</li> </ul>  | <p>A flashing LED indicates normal operation.</p> <p>An LED which is fixed on or off indicates abnormal or interrupted operation.</p>   |
| <ul style="list-style-type: none"> <li>• <b>Red, orange or green Communication LED:</b> indicates the status of the external communication of the flow meter (serial link or USB).</li> </ul> | <p>Flashing green light for each dialog on the serial link.</p> <p>Long red flashing light on each dialog error on the serial link.</p> <p>Fixed orange light when the flow calculation is in degraded mode or when a related function is faulty.</p> <p>Fixed red light when the flow calculation is faulty.</p> |

## 1.11 Screen

- LCD: graphic (14 rows x 20 characters).
- Backlighting: permanent or timed.
- Screen reading: from -20°C to +60°C.



## 1.12 Functions

- **Recording options:** The flow meter is used to record the measurement data (logger function). Up to 30 variables can be recorded (for example: average flow, minimum flow, maximum flow, water level). A total of 530,000 readings can be recorded. The frequency and sequencing of the recordings can be adjusted.
- **Echo display:** It is possible to display the measurement echo for each chord, which allows you in particular to check the quality of the measurement and directly view the effect of certain corrective actions (positioning and alignment of the probes, adjustment of the settings, cleaning of the probes, etc.).
- **Four flow volume totalizers** which can count the positive flows, negative flows or total flows, regardless of their sign,
- **Filtering of the measurement** using a first-order filter allowing the non-significant flow fluctuations to be smoothed,
- **Storage of the measurement** in memory in the event of a momentary loss of the echo (due, for example, to the passing of air bubbles) or other faults (adjustable storage interval),
- **Setting the measurement to zero** if the flow is below a programmable value,
- **Readjustment of the zero** if it is possible to completely stop the flow.

## 1.13 Performance of the flow meter

- Uncertainty over measured speed: up to  $\pm 0.5$  %.
- Repeatability: up to 0.1 %.
- Linearity: up to 0.1 %.
- Typical uncertainty on the flow rate calculation: from 0.5 to 5 % depending on the application and the number of chords.

**Important:** The accuracy of the measurement also depends on the accuracy with which the geometry of the measuring point is measured, the dimensions of the probe pairs, the distance between the probes and the length the wave has to travel between two probes. An inaccuracy on one of these values may compromise the accuracy of the measurement.

## 1.14 Cleaning the flow meter

The box may be cleaned with water, diluted alcohol or detergent using a sponge or a soft cloth. Do not use abrasive materials or solvents.

## 1.15 Recycling the flow meter

In the context of decree no. 2005-829 dated 20 July 2005 relating to the collection, treatment and disposal of electrical and electronic equipment in France, Ultraflux delegates the responsibility for financial and also logistical recovery to the user, who will manage their own waste.

### 1.16 CE marking

The Uf 811 complies with CE certifications:

EN 55016-2-1	Measurement of conducted emissions Criterion A
EN 55016-2-3	Measurement of radiated emissions from 30 MHz – 6 GHz
EN 61000-4-6	Immunity to induced conducted disturbances Criterion B
EN 61000-4-2	Immunity to electrostatic discharges Criterion B
EN 61000-4-3	Immunity to radiated electromagnetic fields Criterion A
EN 61000-4-4	Immunity to rapid transients in bursts Criterion B
EN 61000-4-5	Immunity to shock waves Criterion B
EN 62311	Human exposure to electromagnetic fields

## **CHAPTER 2: SAFETY INSTRUCTIONS**

## 2.1 Using the flow meter

The flow meter, equipped with ultrasonic measuring probes, is used to measure the flow of a fluid (gas or liquid) in a pipe.

It is important to correctly configure the flow meter for its measurement results to be correct. You are recommended to call on qualified staff from Ultraflux to ensure this is the case. This is strongly advised if your equipment is used to regulate a process, intervene in a monitoring system, or in the case of other applications for which an incorrect flow measurement would lead to risks.

In normal operation, the flow meter must not heat up to a level liable to cause burns. It is not necessary to take any particular precautions to allow it to cool. Should the temperature of the unit rise abnormally, it is recommended to power off the flow meter and call Ultraflux for expert advice. In the event of a fire inside the flow meter, power it off without opening or touching it, then call the competent services in order to secure the premises.

The flow meter must not be used beyond the possibilities and specifications given in this manual. The flow meter must be stored in a dry place, with the packaging provided by Ultraflux in order to protect the parts liable to be damaged by a shock. It is recommended to wear PPEs (Personal Protective Equipment) adapted for the handling and installation of the flow meter (safety boots, protective gloves).

The flow meter must only be modified or disassembled by Ultraflux personnel. Ultraflux accepts no responsibility should this rule not be respected. No consumables are used for the operation of the flow meter.

The connectors must only be connected or disconnected with the power off and the equipment isolated.

Ultraflux accepts no responsibility for incidents which may occur following a failure to respect these instructions.

## 2.2 Symbols used on the flow meter



User manual must be read before use



Disconnect the flow meter and power it off before opening the unit or connecting or disconnecting inputs and outputs.

## **2.3 Contact address**

For any requests for information, please contact us at:

ULTRAFLUX

9, Allée Rosa Luxemburg

95610 ERAGNY

FRANCE

<http://www.ultraflux.net>

E-mail : [ultraflux@ultraflux.fr](mailto:ultraflux@ultraflux.fr)

Tel.: 33 (0)1 30 27 27 30

Fax: 33 (0)1 30 39 84 34

2012 ULTRAFLUX S.A.

## **CHAPTER 3: INSTALLATION AND WIRING**

The units do not pose any particular danger to users. It is however recommended to wear personal protective equipment during assembly, including: gloves, safety boots, impact goggles. This equipment will allow you to avoid any risk when installing the flow meter.

It is recommended to follow the assembly method described below in order to avoid any risk of injury.

Assembly must be carried out or inspected by Ultraflux to ensure the unit is leakproof and will operate correctly.


**Important:** Avoid installing the Uf 811 close to a frequency converter. If this cannot be avoided, interference filters must be installed. It is highly recommended to contact us if this situation arises.

It is also recommended to separate the paths of the probe cables and the power cables.

### 3.1 Wall attachment

Make attachment holes on a wall which is sufficiently solid. Firmly screw the flow meter to the wall so that it does not fall (take care with cavity walls).

A clearance of 80 mm must be left around the unit to allow the connectors to be connected.



### 3.2 Wiring instructions

Wiring must be carried out by a person with electrical accreditation. The flow meter must be powered off before installing or uninstalling. The isolation devices must be locked and tagged. The wiring must respect the diagrams provided for the power supply and for the inputs/outputs.

It is sometimes necessary to protect the inputs/outputs, the power supply and the ultrasonic chords. You are strongly recommended to contact Ultraflux to obtain a diagnosis on this point. Ultraflux accepts no responsibility in the event of the incorrect use of the flow meter, and in such cases, the Ultraflux guarantee would not be valid.

### 3.3 Connector wiring

#### Preliminary comments:

- If using an armoured cable, be careful with the "cutting edge" of the armour after cutting it to strip the wire. This edge may be very sharp. It is recommended to cover the cut edge of the armour with insulating tape to prevent any accidents.
- The armour must remain outside the plugs. The shielding must pass through the connector in order to prevent interfering signals from damaging the quality of the measurement. Remember to allow sufficient lengths to be able to access the locations of the probes and the inputs/outputs.
- The length recommendation in the assembly diagrams must be complied with in order to ensure good contact between wire and pin and provide leaktightness.
- The recommended wire cross-sections must be complied with in order to be compatible with the connectors.
- The recommended tightening torques must be complied with in order to ensure leaktightness and the good mechanical strength of the flow meter.

**Note:** All connectors are supplied with the flow meter.

#### Tools required:

- 18 mm open-ended wrenches
- Combination pliers
- Cutting pliers
- Stripping pliers
- Cutter
- 10-m tape
- Torque wrench
- 4 mm flat screwdriver

### 3.3.1 Communication connector



Depending on whether the RS232 or RS485 interface has been selected, connect the RX TX or A, B pins to ground.

#### Notes:

- The serial link is electrically insulated.
- If the UF 811 is the last device on the RS485 network, a termination resistance of 120 Ohm must be added to the connector between pins A and B.
- Only one of the two interfaces may be in operation at any one time.

The connector used is a **male 5-pin M12 type** connector with inverted B coding.

View of the base



The pins have the following functions:



Pin	Functions
1	RS 485 : A / RTx (-)
2	RS 485 : B / RTx (+)
3	RS 232 : Tx (Output Uf 811)
4	RS 232 : Rx (Input Uf 811)
5	GND ISO

**Note:** the pin number is engraved directly on the connector.

**Recommended length to strip, tightening torque and cross-section of cable:**

Cross-section of conductor	0.25 mm <sup>2</sup> ... 0.75 mm <sup>2</sup>
Cross-section of AWG conductor	24 ... 18
External diameter of cable	6 mm ... 8 mm
Tightening torque Wrench M12	0.4 Nm
Tightening torque Screw terminals	0.2 Nm
Tightening torque Set screw	0.8 Nm ... 1 Nm

**Plug fitting:**

<b>a</b> 	<b>a</b> Thread on the parts.
<b>b</b> 	<b>b</b>  Strip the cable by 35 mm. Strip the conductors by 4 mm. Splay the armour and place it around the protector ring. Cut off the excess braiding. Feed the wires through the box. Fit the armour, the packing and the ring clip. Turn the set screw to fasten the cable in place. Screw down the conductor wires. Fit the connector. Firmly tighten the set screw.

### 3.3.2 Input/output connectors

The Uf 811 can contain up to 4 single I/O modules or 2 double I/O modules.


2 connectors (I/O 1 & I/O 2) are provided for connection. Their wiring depends on the type and location of the modules determined when the order is placed.

The location of the modules and their types are shown on the test report supplied with the device when it is delivered.

Locations 1 & 2 are connected to connector I/O 1.

Locations 3 & 4 are connected to connector I/O 2.

The connectors used are **female 8-pin type M12 connectors** with A coding.



For the **I/O 1 connector**, the pins have the following functions:

Pin	Function
1 I/O 1	Location 2 pin 1
2 I/O 1	Location 2 pin 2
3 I/O 1	Location 2 pin 3
4 I/O 1	Location 2 pin 4
5 I/O 1	Location 1 pin 1
6 I/O 1	Location 1 pin 2
7 I/O 1	Location 1 pin 3
8 I/O 1	Location 1 pin 4

For the **I/O 2 connector**, the pins have the following functions:

Pin	Function
1 I/O 2	Location 4 pin 1
2 I/O 2	Location 4 pin 2
3 I/O 2	Location 4 pin 3
4 I/O 2	Location 4 pin 4
5 I/O 2	Location 3 pin 1
6 I/O 2	Location 3 pin 2
7 I/O 2	Location 3 pin 3
8 I/O 2	Location 3 pin 4

### 1) Wiring of the relay modules

The pins have the following functions:

Pin	Function
1	relay A
2	relay A
3	relay B
4	relay B

### 2) Wiring of the current output modules

The pins have the following functions:

Pin	Function
1	current (+)
2	current (-)
3	-
4	-

### 3) Wiring of the current input modules

The pins have the following functions:

Pin	Function
1	current A wire 1
2	current A wire 2
3	current B wire 1
4	current B wire 2

### 4) Wiring of the voltage input modules


The pins have the following functions:

Pin	Function
1	voltage A(+)
2	voltage A(-)
3	voltage B(+)
4	voltage B(-)

## 5) Wiring of the temperature modules

**Comment:** This is a double location module

The sensors Pt 100 and Pt 1000 can be wired in different ways:



The most complete wiring is that using a 4-wire sensor:

Pin	Function
1	red wire 1
2	white wire 1
3	red wire 2
4	white wire 2

**Warning:** To ensure good measurement quality, it is recommended to use shielded platinum probes. 360° shielding connection is provided by the Binder connector.

**Important:** For 2- or 3-wire cables, just use "bridging" to make up for the missing wires. In the 3-wire version, a white wire is missing: simply bridge the two white wire terminals 1 and 2, and place the white cable on the "white wire" pin.

## 6) Example of a module configuration

- Single voltage input module in location 1.
- Single current input module in location 2.
- Double calorimetric module in locations 3 & 4.

For the I/O 1 connector, the pins have the following functions:

Pin	Function
1 I/O 1	current (+)
2 I/O 1	current (-)
3 I/O 1	-
4 I/O 1	-
5 I/O 1	voltage A(+)
6 I/O 1	voltage A(-)
7 I/O 1	voltage B(+)
8 I/O 1	voltage B(-)

For the I/O 2 connector, the pins have the following functions:



Pin	Function
1 I/O 2	red wire 1 probe 2
2 I/O 2	white wire 1 probe 2
3 I/O 2	red wire 2 probe 2
4 I/O 2	white wire 2 probe 2
5 I/O 2	red wire 1 probe 1
6 I/O 2	white wire 1 probe 1
7 I/O 2	red wire 2 probe 1
8 I/O 2	white wire 2 probe 1

## 7) Plug fitting instructions

### Recommended length to strip, tightening torque and cross-section of cable:

Cross-section of conductor	0.25 mm <sup>2</sup> ... 0.75 mm <sup>2</sup>
Cross-section of AWG conductor	24 ... 18
External diameter of cable	6 mm ... 8 mm
Tightening torque Wrench M12	0.4 Nm
Tightening torque Screw terminals	0.2 Nm
Tightening torque Set screw	0.8 Nm ... 1 Nm

### Plug fitting:


<p><b>a</b></p> 	<p><b>a</b></p> <p>Thread on the parts.</p>
<p><b>b</b></p> 	<p><b>b</b></p> <p>Strip the cable by 35 mm. Strip the conductors by 4 mm. Splay the armour and place it around the protector ring. Cut off the excess braiding. Feed the wires through the box. Fit the armour, the packing and the ring clip. Turn the set screw to fasten the cable in place. Screw down the conductor wires. Fit the connector. Firmly tighten the set screw.</p>

### 3.3.3 Probe and chord connector

Each connector (chord connector 1 & chord connector 2) relates to one ultrasound chord, namely two probes. As standard, it is therefore necessary to use the Y-cable provided with the flow meter in order to separate the two probe cables. The flow meter may be configured with only one probe per connector, but the number of possible chords is then divided by two. You are recommended to contact Ultraflux in order to define the best configuration for your application.

The connector used is a **male 4-pin M12 type** connector with A-standard coding.

View of the base



**NB:** pin 5 on base plate 5 is not used.

The **pins** have the following functions:



Pin	Function
1	upstream probe wire A
2	upstream probe wire B
3	downstream probe wire A
4	downstream probe wire B

**Note:** each pin number is engraved directly on the connector.

#### Recommended length to strip, tightening torque and cross-section of cable:

Cross-section of conductor	0.25 mm <sup>2</sup> ... 0.75 mm <sup>2</sup>
Cross-section of AWG conductor	24 ... 18
External diameter of cable	6 mm ... 8 mm
Tightening torque Wrench M12	0.4 Nm
Tightening torque Screw terminals	0.2 Nm
Tightening torque Set screw	0.8 Nm ... 1 Nm

### Plug fitting:

<b>a</b> 	<b>a</b> Thread on the parts.
<b>b</b> 	<b>b</b> Strip the cable by 35 mm. Strip the conductors by 4 mm. Splay the armour and place it around the protector ring. Cut off the excess braiding. Feed the wires through the box. Fit the armour, the packing and the ring clip. Turn the set screw to fasten the cable in place. Screw down the conductor wires. Fit the connector. Firmly tighten the set screw.


### 3.3.4 Power supply connector

**Warning:** Before wiring the power supply, check that no current is circulating on the power supply cables. The installation must be locked and tagged so that it cannot be inadvertently powered on, for example by someone other than the user.

**Important:** Ensure the flow meter is powered off before removing the power supply connector. The flow meter may suffer irreversible damage should the power supply connector be removed whilst the flow meter is powered on.

1. Install the protective grounding braid on the dedicated screw.
2. Install the V+, 0V and ground wires on the connector.

The connector used is a **female 4-pin M12 type connector** with Speedcon A-standard coding.



The **pins** have the following functions:

Pin	Function
1	VIN + 10-32 VDC
2	VIN – 0V
3	GROUND
4	not connected

#### Recommended length to strip, tightening torque and cross-section of cable:

Cross-section of conductor	0.25 mm <sup>2</sup> ... 0.75 mm <sup>2</sup>
Cross-section of AWG conductor	24 ... 18
External diameter of cable	6 mm ... 8 mm
Tightening torque Wrench M12	0.4 Nm
Tightening torque Screw terminals	0.2 Nm
Tightening torque Set screw	0.8 Nm ... 1 Nm


#### Plug fitting:

<p>Thread on the parts.</p>	<p>Strip the cable by 35 mm.  Strip the conductors by 4 mm.  Splay the armour and place it around the protector ring.  Cut off the excess braiding.  Feed the wires through the box.  Fit the armour, the packing and the ring clip.  Turn the set screw to fasten the cable in place.  Screw down the conductor wires.  Fit the connector.  Firmly tighten the set screw.</p>

### 3.4 Ground connection

For the ground connection, it is recommended to use a copper braid. When choosing the braid, it is important to respect the following rule:


$$\text{Length} / \text{Width} < 3$$



### 3.5 Connection

Once the unit is fixed and the cables installed in the connectors, the probe connectors, input/output connectors, communication connector and finally (last of all) the power supply connector must be screwed into their allocated positions.

The connectors of the Uf 811 box are installed as shown on the figure below:



**Important:** All connectors must be connected with the equipment powered off, isolated and locked and tagged, by authorized staff. The power supply connector must be the last to be connected.

Screw the connector to the cable using the torque intended for the connector.

**Note:** If a connection is not used, cap it off at the Uf 811 in order to maintain IP67 leaktightness.

## **CHAPTER 4: INSTALLING A MEASURING POINT**

## 4.1 Composition of a measuring point

Apart from the electronic converter (the unit), a measuring point includes the following components:

- 1 to 2 pairs of probes
- 1 to 4 special cables for the probes (provided by Ultraflux)

## 4.2 Choosing the measurement location


It is essential to follow the instructions given in our document "Ultrasonic transit time flowmeter". As a reminder, the main precautions to be taken are as follows:

### 4.2.1 Straight lengths to be used


#### 1) Monochord measurement

Using a monochord measurement implies that the speed profile at the measuring point is symmetrical relative to the axis of the pipe, and is fully developed and stable.

The following three conditions are not fulfilled in an area of disturbed flow, for example, at the outlet from an elbow or downstream from a regulating valve:




*The speed profile is stable but not symmetric relative to the axis of the pipe.*




*The symmetry of the speed profile varies relative to the pipe axis but is neither stable nor fully developed.*

This is why probes need to be placed on a straight section of pipe sufficiently far upstream or downstream of a hydraulic disturbance (narrowing or widening of the pipe, elbow, pump, etc.).


The following values show, for liquids, the minimum distances (L) to comply with before and after a disturbance depending on the internal diameter of the pipe (D) for the errors induced by these disturbances to be less than  $\pm 1\%$ .




In reflex mode :  $L \geq 30.D$   
In direct mode :  $L \geq 40.D$



In reflex mode :  $L \geq 3.D$   
In direct mode :  $L \geq 5.D$




In reflex mode :  $L \geq 10.D$   
In direct mode :  $L \geq 15.D$



En mode reflex mode :  $L \geq 3.D$   
En mode direct mode :  $L \geq 5.D$



#### **Comment:**

The values shown must be multiplied by 2.5 for gases.




In reflex mode :  $L \geq 15.D$   
In direct mode :  $L \geq 20.D$


In reflex mode :  $L \geq 3.D$   
In direct mode :  $L \geq 5.D$




In reflex mode :  $L \geq 15.D$   
In direct mode :  $L \geq 20.D$




In reflex mode :  $L \geq 3.D$   
In direct mode :  $L \geq 5.D$




In reflex mode :  $L \geq 15.D$   
In direct mode :  $L \geq 20.D$




In reflex mode :  $L \geq 3.D$   
In direct mode :  $L \geq 5.D$




In reflex mode :  $L \geq 15.D$   
In direct mode :  $L \geq 20.D$



In reflex mode :  $L \geq 5.D$   
In direct mode :  $L \geq 8.D$



In reflex mode :  $L \geq 30.D$   
In direct mode :  $L \geq 40.D$




In reflex mode :  $L \geq 3.D$   
In direct mode :  $L \geq 5.D$

## 2) Multichord measurement


As multichord measurement copes better with irregularities in the speed profile, multichord measurements can be used on straight lengths much smaller than those required for a monochord measurement.

For example, we have been able to test a measurement made using 4 parallel chords placed at  $1.6 D$  from a T followed by a butterfly valve. The error under these very unfavourable conditions was 2 %. Under the same conditions, a monochord measurement would have generated an error of the order of 10 %.

### Recommended locations



*Vertical pipes with rising flow*




*Low points of horizontal pipes*



*Siphon mounting for pipes with a slight slope*

### Locations not recommended




*Vertical pipe with downflow, particularly in the case of free flow.*

*High points*

### 4.3 Choosing the probe location


The installation depends on the type of probe.

#### 4.3.1 Intrusive probes



Two geometric modes may be applied:

- *Diametric mode:* The chord follows the diameter of the cross-section. An approach by Kh is then activated in order to model the speed profile and refine the measurement. The Kh coefficient takes account of the roughness of the wall and the viscosity of the fluid. You are strongly recommended to refer to the teaching manual available on request in order to understand the significance of these settings.
- *Parallel mode:* The chords are placed in parallel planes which "section" the fluid speed flow better.




**Note:** The accuracy of the measurement is improved by increasing the number of chords.

**Important:** With a "simple" configuration, diametric mode must be used. Parallel mode is available from "normal" configuration level.

For each chord, enter the length (in meters) between the faces of the two probes. To help you, read our document "Ultrasonic transit time flowmeter".


Also enter the projected length (Daxe) of this measurement relative to the axis of the pipe.

#### 4.3.2 External probes (clamp-on)




External probes may be mounted in several configurations depending on the number of ultrasound wave reflections on the wall of the pipe:


- Direct or / configuration:




- Reflex or V configuration:



- N (or Z) configuration:



- W configuration:



**Note:** The longer the travel, the more accurate the measurement.

On the other hand, the ultrasound echo will be weaker the longer the distance and therefore difficult to measure. A compromise must therefore be found between accuracy and ease of finding the ultrasounds. This compromise depends on the application (fluid, quality of the wall, diameter, etc.).

## 4.4 Installing probes and connectors

The care taken to install the probes (sensors) and their alignment determines the accuracy of the flow measurement.

### 4.4.1. Permanent external (clamp-on) probes

#### 1) Preparing the pipe

To install external probes (clamp-on), the areas of pipe where the sensors are to be installed must have been carefully cleaned beforehand. The pipe must be cleaned using absorbent paper or a piece of cloth. If the pipe is very dirty or corroded, use a metal brush or scraper. It is not necessary to remove good paintwork. It is even recommended to keep it to avoid corrosion. The same applies to most plastic coverings. On the other hand, if the paint is blistered or flaky (test by scratching with your nail or a pointed tool), it should be removed locally.

Then coat the locations where the probes are to be installed lightly with grease (do not use silicon grease).

#### 2) Installing the elastomer strip

To start, cut a piece of strip to the size of the probe (+5 mm).

Then remove the plastic protective film.

Apply the strip where the probe is to be installed.

Lastly, lightly grease the external surface of the strip.

#### 3) Installing the probe

Place the probe on the strip and fix it in place by firmly tightening the stainless steel collar supplied.

Preferably position the collar locking screw on the opposite side to the probe.

### 4.4.2. Temporary external (clamp-on) probes

#### 1) Preparing the pipe


To install external probes (clamp-on), the areas of pipe where the probes are to be installed must have been carefully cleaned beforehand. When doing this, take into consideration the distance between the probes and estimate the space required for probe/mounting assembly. The pipe must be cleaned using absorbent paper or a piece of cloth. If the pipe is very dirty or corroded, use a metal brush or scraper. It is not necessary to remove good paintwork. It is even recommended to keep it to avoid corrosion. The same applies to most plastic coverings. On the other hand, if the paint is blistered or flaky (test by scratching with your nail or a pointed tool), it should be removed locally.

#### 2) Selecting and installing the coupling medium

A coupling medium must be selected which is suited to the humidity and temperature conditions of your application.

- "traditional" gel for temporary measurements at ambient temperature and without too much humidity,
- high temperature gel (<300°C),
- grease in the case of high humidity (quality depending on temperature).

After choosing a suitable coupling medium, spread it lightly around the locations chosen for installing the probes and copiously on the probes themselves.



### 3) Installing the probe

Attach the probes onto the pipe using straps or a dedicated support. Check the presence and continuity of the coupling medium (ensure no air layer forms between the pipe wall and the probe). To avoid this pitfall, refrain from sliding the probes too much (the coupling medium film could be altered/broken).

#### 4.4.3. Inserted probes

**Preliminary comment:** before you do anything, you must check with Ultraflux whether your probes can be extracted under load or not. Whether an inserted probe may be extracted under load or not is determined by the probe used and the application conditions of your measuring point (pressure, fluid measured, etc.).

##### 1) Flanged probes



1<sup>st</sup> step: Check the position of the bosses relative to the drawing provided by Ultraflux

2<sup>nd</sup> step: Check the state of the seal face which must be free of irregularities and dirt. Seal faces which are rusted, battered or generally in a bad state of repair must not be used.

3<sup>rd</sup> step: Insert the probe into the boss making sure the seal is present.

4<sup>th</sup> step: Insert the probe fixing screws and tighten them to the recommended tightening torques.

5<sup>th</sup> step: Connect the probes to the flow meter through the connecting head.

## 2) Screw probes



1<sup>st</sup> step: Check the position of the bosses relative to the drawing provided by Ultraflux

2<sup>nd</sup> step: Check the state of the seal face which must be free of irregularities and dirt. Seal faces which are rusted, battered or generally in a bad state of repair must not be used.

3<sup>rd</sup> step: Insert the probe into the boss making sure the seal is present.

4<sup>th</sup> step: Screw the probe down into the boss as far as it will go, then readjust so that the alignment marker of the probe is on the axis of its twin probe.

5<sup>th</sup> step: Carry out the previous steps from step no. 2 with the twin probe.

6<sup>th</sup> step: Connect the probes to the flow meter via the connection head or the push/pull connector (depending on the type of probe).

7<sup>th</sup> step: Readjust the alignment of the probes checking the gain displayed by the flow meter.

## 3) Probes with air lock



1<sup>st</sup> step: Check the position of the bosses relative to the drawing provided by Ultraflux

2<sup>nd</sup> step: Check the state of the seal face which must be free of irregularities and dirt. Seal faces which are rusted, battered or generally in a bad state of repair must not be used.

3<sup>rd</sup> step: Install the valve checking the presence of the seal. Screw the air lock onto the valve - at all times checking the presence of the seal.

4<sup>th</sup> step: Press the operating rod down as far as it will go then screw the guide into the air lock.

5<sup>th</sup> step: Orientate the packing gland in the axis of the twin probe.

6<sup>th</sup> step: Carry out the previous steps from step no. 2 with the twin probe.

7<sup>th</sup> step: Connect the probes to the flow meter via the connecting head.

8<sup>th</sup> step: Readjust the alignment of the probes checking the gain displayed by the flow meter.

## **CHAPTER 5: USING AND CONFIGURING THE Uf 811**

## 5.1 Using the Uf 811

The Uf 811 has a screen and a keypad which can be used to configure and view the measurements as they are taken. LEDs indicate the status of the measurement and of the flow meter communication.



### 5.1.1 Operating mode

Uf 811 flow meters operate in 3 modes (3 types of screen):

- Measurement mode (flow rate, speed, gain, quality index, etc.) which includes all the measurement screens,
- Configuration mode (section description, logger, etc.) which includes all the configuration screens
- Echo Display mode (portrait, zoom) which includes all the echo display screens.

### 5.1.2 Keypad

- Changing from one type of screen to another is done by using the **"Fn"** (for Function) key. This **"Fn"** key in particular is used to enter *configuration* mode. The ◀ and ▶ keys allow the user to browse through the menus for this mode.
- A long press on the **"Fn"** key, or allowing approximately 1 minute to pass without using the keypad, returns you to *measurement* mode.
- Within a menu, the ◀ and ▶ keys are used to change page. These keys may also have a contextual function which in this case will be shown at the bottom of the screen page, such as that of selecting the measurement mode screen which is displayed by default.
- After powering on the Uf 811, the screen displays the page which has been selected as priority. To choose this "default" screen, select and validate it by pressing the **"B"** key in *measurement* mode.
- To scroll through the measurement screens, use the ▲ and ▼ keys.
- To access the other menus, press the **"Fn"** key, then successively press the ◀ key, or browse using the ◀ and ▶ keys.
- To enter a menu, press ▲ or ▼. To change page, press **"A"** or **"B"**. To change a row, select it using ▲ or ▼ and change the value using ◀ or ▶.
- If no key is pressed for approximately one minute, the Uf 811 automatically returns to measurement mode and to the display chosen as priority using **"B"**.
- For a given parameter, the value to be applied is defined using the ▶ (increase) and ◀ (decrease) keys. An extended press on one of these two keys accelerates the increase or the decrease.

## 5.2 Main configuration elements

### 5.2.1 Number of channels

**Note:** for multi-channel flow meters only, it is possible to define the number of channels to be managed by the flow meter.

The geometric and physical description of the measuring point must then be produced for each channel.

In the case of several channels, the channels are named in alphabetical order (A, B...).  $Q_a$ ,  $Q_b$ ... are the flows calculated for each channel.  $Q_t$  is the total flow.

### 5.2.2 Description of the pipe

The pipe is described by its outside diameter (or equivalent sectional diameter) and the physical characteristics of the material(s) of which it is made.

- *In "simple" configuration:* you must define the outside diameter, the thickness of the material and the type of material. The fluid must be water.
- *In "normal" configuration:* you can choose the fluid from a list. This list depends on your flow meter type (gas or liquid).
- *In "advanced" configuration:* you can define 3 different wall thicknesses to configure a wall in composite materials.

Two different types of probe may be used:

- *External (clamp-on) probe:* the probe is "placed" on the outside of the pipe. The "clamp-on" probes may be positioned in direct (/), reflex (V), N or W configurations.
- *Intrusive mode (wet probe):* a hole must be drilled in the pipe to install the probes, or the probes must be installed directly on a sleeve (welded or fixed by flange). Intrusive probes can be placed in parallel or diametric planes.


**Note:** The number of chords must be chosen depending on your application and the authorised limit for your flow meter type.

## 5.3 Configuring the Uf 811

The configuration for the flow meter is divided into three levels:

- Simple: simplified configuration for basic use of the flow meter.
- Normal: configuration allowing more detailed use.
- Advanced: mode allowing the complete adjustment of the flow meter settings. This mode is reserved for users with detailed knowledge of the transit time difference flow measuring technique and with some idea of hydraulic concepts.

The level can be changed by selecting the menu option Configuration/Settings/Simple, Normal or Advanced:



This menu is also used to activate functions such as

- the logger,
- the inputs/outputs,
- the totalizers.

To activate these options, place the cursor on the line corresponding to the required option and use the < and > keys.

### 5.3.1 Flow meter menu ("Settings" mode)

Depending on the type of flow meter and the configuration mode (simple, normal or advanced) selected, the flow meter menu may change. Below is a non-exhaustive list of the sections for the flow meter:

- CONFIGURATION: configuration of the operating modes, the registration name, the JBUS/MODBUS characteristics; configuration management, etc.
- PIPE/FLUID CONFIGURATION: setting of the type of fluid, the pipe, the chords, the geometry of the chords of the measuring point, etc.
- TOTALIZER CONFIGURATION: configuration of totalizers.
- INPUT/OUTPUT CONFIGURATION: configuration of inputs and outputs.
- LOGGER CONFIGURATION: configuration of the logger.
- LINEARISATION CONFIGURATION: configuration of linearisation.
- FUNCTION CONFIGURATION: settings of the inputs for the function engine. This menu is only available on request for specific applications.
- ADVANCED CONFIGURATION: settings of the simulation mode, the special probes, the specific codes for ultrasonic treatment, etc.
- ECHO DISPLAY: display of the echo signals of the ultrasonic probes.
- FIRMWARE UPDATE: update of the firmware

## 5.4 SIMPLE configuration

Below you will find the description of the menus, screen by screen, to guide you through the configuration of your flow meter.

### 5.4.1 "Configuration" Menu

```
--- OPTION FILES ---  
  
Load Option File  
N 0:UF 8x1  
  
Save Option File  
N 0:UF 8x1
```

#### 1) "Config. Files" Window

This window lets you load and save your configurations. The current configuration of the flow meter can be saved directly in the flow meter, or on a PC. Up to 11 configurations can be saved, numbered from 1 to 11.

To save the current configuration on the flow meter, select the configuration number under which you wish to save it. The saving of the configuration is then confirmed when passing to another menu page or following an extended press of the **Fn** key. The name of the configuration is the same as the station name (see point 8).

To recall a configuration, enter the configuration number and confirm this choice by passing to another menu page.

Remember to save the current configuration in order not to lose it.

```
-- SETTINGS RESET --  
NO  
---Confirmation---  
NO  
  
----- SETTINGS -----  
Advanced  
  
----- MENU -----  
Totalizer = Enable  
Logger = Enable  
I/O = Enable
```

#### 2) Reinitialisation

This command reinitialises the flow meter (to factory configuration).

#### 3) Confirmation (of reinitialisation)

Reinitialisation of the flow meter requires the user to enter a field requiring confirmation (protection against handling errors).

#### 4) Configuration

This command allows the configuration level of the flow meter to be changed (Simple, Normal or Advanced).

#### 5) Menus

Allow the user to enable or disable:

- the logger,
- the inputs/outputs,
- the totalizers.

```
Code access = 0
LANGUAGE : ENGLISH
-- STATION'S NAME --
UF 8x1
---- BACK LIGHT ----
Timed
--CONNECTION 1: PC--
N JBUS/MODBUS: 1
Bitrate : 115200
```

#### 6) Access code

The flow meter is initially delivered without an access code (access code is 0), allowing you to freely modify all the settings. The introduction of a valid code is used to prohibit the modification of the settings for anyone who does not have the code. The settings can then be viewed freely, but cannot be modified.

The code comes into operation when the flow meter returns to measurement mode. The code must be entered in order to exit this mode. If the code is incorrect, the flow meter is locked for a few seconds. The time for which the flow meter is locked increases each time that an incorrect code is entered by the user.

##### Notes:

- The flow meter can be locked manually. Select the "Locked" field and set it to "YES".
- The code can be modified using the keypad (it is then defined using the < and > keys) or the serial link.

**Important:** For writing operations via the serial link or USB, the code must be "written" before any "writing" frame. The flow meter is automatically locked after 10 seconds without any "writing". Each incorrect attempt at entering the code increases the time before the next attempt can be made.

#### 7) Language

The possible display languages are: French, English, Spanish, German, Italian, Portuguese and Russian.

#### 8) Station name

Each flow meter can be assigned a label with up to 8 characters (registration number). The position of the current character is chosen using the ▼ and ▲ keys. To scroll through the characters, use the < and > keys.

## 9) Back light

The possible options are:

- ON: the back light is on for one minute after pressing any key, then remains dimly lit,
- TEMPO: the back light is on for one minute after pressing any key, then goes off,
- OFF: No back light.

## 10) Link

- Configuration of the serial link  
Enter the JBUS/MODBUS number of the flow meter (number assigned to the flow meter and to which it will respond on a JBUS/MODBUS query).
- Transmission speed  
Enter the transmission speed that you wish to apply.

## 11) Timer before return to "Measurement" mode

The flow meter automatically returns to the Measurement screens after approximately one minute. The modified settings are then be taken into account. This avoids the risk of forgetting to exit "Configuration" mode and needing to intervene again on the flow meter to return to "Measurement" mode.

### 5.4.2 "Pipe/fluid configuration" menu

In "simple configuration" mode, access to the settings is restricted to the following sections:

#### 1) Number of chords

Enter the number of chords for your application

#### 2) Flow rate unit (Q unit)

Enter the flow unit which will be displayed.

#### 3) Flow graph

----- PIPE A -----	
Nbr of chords	= 2
----- General -----	
Q Unit	= m <sup>3</sup> /h
----- Graph -----	
Q Period	= 1s
Q Qmin	= 0.0
Q Qmax	= 10.0

The flow graph is one of the Measurement screens. This shows the changes in a particular magnitude in the form of a curve (see the possible magnitudes below).

Enter the minimum and maximum limits of the dimension associated with the flow graph. These limits mark the boundaries of the vertical display of the flow graph.

The flow graph Period setting is used to define the time interval between two successive points. The possible values are: 1 s, 5 s, 10 s, 30 s, 1 min, 2 mins, 5 mins, 10 mins, 15 mins, 30 mins, 1 hr, 2 hrs, 6 hrs, 12 hrs and 24 hrs.

Example: If the period of the flow graph is 1 min, each point of the curve represents the average value of the magnitude associated with the flow graph over 1 min and the whole screen shows the evolution of the flow over the last 144 minutes.

#### 4) Chord settings

For each chord, the two settings to be selected are the reference number of the probes used and the probe fitting type:

```

----- PIPE A -----
-----Chord 1-----
Probe      = SE1515/10
Mounting   = U

-----Chord 2-----
Probe      = SE1515/10
Mounting   = U

```

If the reference number of the probes you are using does not appear in the list, please contact Ultraflux.

#### 5) Type of fluid

In "simple" configuration mode, the fluid must be water at ambient temperature (cannot be modified).

#### 6) Definition of the pipe

The pipe diameter, thickness and material must be defined.

```

----- PIPE A -----
-----Tube-----
Ext.Diam.= 587.21mm
Ext.Circ.= 1844.77mm
-----Wall-----
Material 1= COPPER
Thick. 1= 9.25mm
Material 2= NONE
Material 3= NONE

```

### 5.4.3 "Totalizer configuration" menu (if enabled)

```
----- TOTALIZER 1 -----  
Dir.= + Value =QA  
Pulse Weight  
100 m³  
  
----- TOTALIZER 2 -----  
Dir.=OFF
```

#### 1) Activation and counting direction

For each of the totalizers, the possible modes are:

- **OFF**: totalizer not enabled,
- **+**: totalling of the positive flows, in other words going from the upstream probes to the downstream probes (see the wiring of the probes),
- **-**: totalling of the negative flows, in other words going from the downstream probes to the upstream probes,
- **±**: totalling of all flows, whatever the direction.

**Note:** In addition to flow totalling, other magnitudes from the function engine may be totalled if this is enabled. Contact Ultraflux for further details on this option.

#### 2) Pulse unit and weight

Each activated totalizer emits an incrementation pulse (which can be returned on a relay output; see section 5.4.4 - point 5) each time that the Pulse weight x Unit volume flows in the metering direction of the totalizer.

The possible units include (but are not limited to): 1ml, 1l, 1m3, 1000 m3, 1Gal, 1Bbl...

#### 3) Resetting a totalizer (if authorised)

Resetting totalizers is inhibited when the flow meter leaves the factory. This feature enables the totalizer to be used as a forgery-proof meter and as such able to be used for internal billing (by mutual agreement between the 2 parties).

On request and before shipping, it is possible to authorise the resetting of totalizers.

On site, only an Ultraflux operative will be able to reset the totalizers.

To reset a totalizer (if authorised):

1. Switch to measurement mode (long press on the **Fn** key) on the page of the totalizer concerned,
2. Press the **A** key until the totalizer that you wish to reset is displayed on the right,
3. Press the **B** key to reset the totalizer. A negative image of the pop-up menu is then displayed.

```
----- TOT1(QA +) I27  
399654510 100 m³  
  
<--> RES Tot1
```

#### 5.4.4 "Inputs/Outputs" menu (if enabled)

The input/output modules are:

- On input:
  - Current,
  - Voltage,
  - Temperature (PT100/PT1000),
  - Contact.
- On output:
  - Current/Voltage,
  - Relay.

The menu only appears if inputs or outputs are installed on the flow meter. To install additional inputs/outputs, please contact Ultraflux to find out the specifications of all available inputs/outputs.

##### 1) Current input and voltage input module

<pre>- INPUT/OUTPUT 2 - ---Input A 4/20mA--- Function = Simulate Value = Input           02-A 4mA = 0.350 Range = 4.000  Sim. Value = 1.875  Wiring -----&gt; 02-A</pre>	<pre>- INPUT/OUTPUT 3 - ---Input B 0/10V--- Function = ON Value = Input           03-B 0 V = 0.000 Range = 0.061 Filter = 10 s Memory = 60 s  Wiring -----&gt; 03-B</pre>
--	---

The possible options are:

- OFF: disabled,
- ON: enabled,
- Simulation.

For ON and Simulation, the following must be defined:

- the value corresponding to 4 mA (for a current input),
- the value corresponding to 0 V (for a voltage input),
- the sensor range,
- the value to be simulated (in simulation mode),
- the value of the filter and the memory (in ON mode).

## 2) Temperature input module

The possible options are:

- OFF: disabled,
- PT100-PT1000 mode 2-, 3- or 4-wire (for further details, contact Ultraflux).

Define:

- the type of sensor, Pt 100 or Pt 1000,
  - the type of assembly, 2-wire, 3-wire or 4-wire,
  - the value of the filter and the memory,
  - any offset.
- Simulation: Enter the temperature value to be simulated.

## 3) Contact input module

The possible options are:

- OFF: disabled,
- Status: whether the contact is open or closed,
- Pulse: the number of opening - closing cycles of the contact.

## 4) Current/voltage output module

```
- INPUT/OUTPUT 4 -  
---Analog output---  
Function = 4-20mA  
Value = Pipe A  
4 mA = 0.000  
Range = 16.000  
I fault = 3.600mA  
Sim. Value = 5.252mA  
  
Wiring -----> 04-A
```

The possible options are:

- OFF: disabled,
- Voltage output:
  - 0-5 V,
  - absolute value |0 - 5 V|.
- Current output:
  - 0-20 mA, 4-20 mA, 0-24 mA,
  - absolute value |0-20 mA|, |4-20 mA|, |0-24 mA|.

For the voltage output and current output choices, the following must be defined:

- the parameter that the output represents. Select the magnitude that you wish to associate with the analogue output using the chapter headers (function) and the chapter items (value).
- the bottom of the scale:
  - value corresponding to 0 mA or 4mA (for a current output),
  - value corresponding to 0 V (for a voltage output).
- the range,
- the value in the event of a fault in mA (for a current output) or in volts (for a voltage output).

**Comment:** This module can be used as a current or voltage generator.

## 5) Relay output module

Each relay output may be configured according to one of the following operating modes:

- *Open*: The relay remains constantly off.
- *Closed*: The relay is on if the Uf 811 is powered on, and off if it is not powered on. This choice therefore allows the relay to be used to detect the presence of the power supply (positive safety).

```
- INPUT/OUTPUT 1 -  
---Relay Output B---  
Function = OPEN  
  
Rel. Stat= OPEN  
  
Wiring -----> 01-B
```

- *Totalizer*: The relay generates a pulse with an adjustable width on each incrementation of the selected totalizer.

```
- INPUT/OUTPUT 1 -  
---Relay Output A---  
Function = TOT  
Value = General  
Step = 50 ms  
  
Wiring -----> 01-A
```

The pulse width must then be defined, determining the time for which the relay remains closed (the relay, initially off, is then on for half of the period, then off again for at least the same duration).

The value of the relay period must be less than the weight of the pulse divided by the flow rate.

Example:

Flow rate = 1000 l/s / Pulse weight = 100 l.

We therefore have 1 pulse every  $100/1000 = 100$  ms.

The value of the period must therefore not exceed 100 ms otherwise not all pulses emitted by the totalizer will be counted.

- **Fault:** Depending on the polarity chosen (NO: normally open, NC: normally closed), the relay changes state when the associated fault occurs.

```

- INPUT/OUTPUT 1 -
---Relay Output B---
Function = FAULT
Polarity = NO
Value = General
QT

Rel. Stat= CLOSE

Wiring -----> 01-B


```

In the example, the variable selected is "general Q". This means that the relay closes when the flow meter is not measuring a flow and remains open otherwise.

- **Direction:** Depending on the polarity chosen (NO: normally open, NC: normally closed), the relay changes state when the sign (+ or -) of the associated magnitude changes.
- **Threshold:** Depending on the polarity chosen (NO: normally open, NC: normally closed) and the direction in which the threshold is crossed, the relay takes one state if the value is greater than the indicated threshold. The relay switches to the opposite state if the value concerned is lower than the threshold.

**Comment:** In order to restrict the relay backlash when the dimension concerned fluctuates around the threshold, hysteresis must be defined.

The diagram below illustrates this principle with hysteresis at 2 % and the threshold crossed in the ascending direction:



```

- INPUT/OUTPUT 1 -
---Relay Output B---
Function = THRESHOLD
Polarity = NO
Value = Pipe A
Q
Thres. Va= 57.341
Alarm = Rising
Hystérésis= 2.00%

Rel. Stat= OPEN

Wiring -----> 01-B

```

- **Frequency:** The frequency at which the relay is opened and closed depends on a value to be defined. Example: high flow, high frequency, low flow, low frequency.

```

- INPUT/OUTPUT 1 -
---Relay Output B---
Function = FREQUENCY
Value = Pipe A
Q
0 Hertz = 57.341
Range = 0.200
F fault = 0 hz
Sim. Value = 0.0Hz

Wiring -----> 01-B

```

The following must be defined:

- the parameter that the output represents.  
Select the magnitude that you wish to associate with the output using the chapter headers (function) and the chapter items (value).
- the value relating to 0 hertz.
- the value relating to 1 Khertz.
- the value if a fault occurs.

The relays may be tested individually: select the open or closed mode on the relay state line.

```
- INPUT/OUTPUT 1 -  
---Relay Output B---  
Function = OPEN  
  
Rel. Stat= OPEN  
  
Wiring -----> 01-B
```

#### 5.4.5 "Logger settings" menu (if enabled)

```
----LOGGER RESET----  
NO  
----Confirmation----  
NO  
-Nbr of Parameters--  
5  
----Logger Mode----  
Cyclic  
----Logger Step----  
1mn  
----Logger Range----  
124d 7h33mn
```

**Important:** The logger must be reset before the number of variables is changed.

##### 1) Resetting the logger

To reset the logger, enter "YES" in the "RESET LOGGER" field.

##### 2) Confirmation of resetting the logger

Resetting the logger requires the user to enter a confirmation field (protection against handling errors).

##### 3) Number of parameters for the logger

Up to 30 variables can be recorded in the logger. The number of variables can be adjusted. Its maximum autonomy is for 530,000 time-stamped readings.

##### 4) Logger mode

The logger has 2 recording modes: "rotating" (initial files overwritten when the logger is full) or "Stop when full" (the logger stops operating when it is full).

##### 5) Logger interval

The recording period of the logger can be set from 1s to 24 hrs: 1 s, 5 s, 10 s, 30 s, 1 min, 2 mins, 5 mins, 10 mins, 15 mins, 30 mins, 1 hr, 2 hrs, 6 hrs, 12 hrs and 24 hrs.

##### 6) Logger autonomy

This field, which cannot be changed, shows the remaining autonomy of the logger.

## 7) Logger variables

For each of the variables of the logger, one of the following functions can be selected:

-----	VALUE 1	-----
General		
Status		
-----	VALUE 2	-----
Pipe A		
Q		AV.
-----	VALUE 3	-----
Pipe A		
H. water		AV.
-----	VALUE 4	-----
Pipe A		
U		AV.

- *AVG*: average value over the recording period,
- *MIN*: minimum value over the recording period,
- *MAX*: maximum value over the recording period.

## 8) Log on variation


The variation mode of the logger is used to reduce the recording period for the data in the logger.

To do this, define the maximum variation percentage with regard to the previous recording. If the variation measured is greater than this maximum, recording is instantly triggered (no more than once per second).

records	Variation
= YES	
----- VALUE 1 -----	
Pipe A	
Q	1.0%
----- VALUE 2 -----	
Pipe A	
Q	0.1%
----- VALUE 3 -----	
Pipe A	
Q	0.0%

**Comment:** A percentage equal to 0% disables the associated value.

The following figure shows the reduction in the period of the logger when the flow experiences a variation:



The vertical lines (blue) show when logger recording is triggered. If the variation of the flow is greater than the configured threshold, the logger forces a recording.

### 5.4.6 "Echo display" menu

**Warning:** Echo display mode blocks the measurement function (The measurement values are no longer calculated, the logger no longer records data).


"Echo analysis" mode is used to view the acoustic signal of each chord, which is of use during the commissioning or maintenance phase, or for example:

- to check the connection of the probes and that they are working correctly,
- to check that the probes are placed at the correct distance,
- to find the origin of a measurement incident (clogging of the probes, obstruction of the structure between the probes, unforeseen pollution, rupture of a probe cable, etc.).

**Comment:** Various characteristic signals are analysed in appendix 1.

"Echo analysis" mode includes two screens per chord:


- The first displays the acoustic signal between the emission (for short travel times) and the echo analysis zone. This screen is called the "landscape" display:



- The two dashed vertical lines show the area where the echo is expected. An echo received outside of this area will not be taken into account.
- The dotted vertical line shows the measuring point on the echo.
- The chord number is shown underneath the graph.
- On the top left of the screen is shown the gain applied to the echo and the travel time of the wave.

**Comment:** If no acoustic signal reaches the expected zone (for example if one of the probes is not connected, or if one of the probe cables is damaged), the screen displays a "!" sign in place of the acoustic signal.

- The second screen shows a zoom on the echo chosen for the measurement. This screen is called the "zoom display":



- The continuous horizontal line shows the noise level.
- The vertical dotted bar marks the location where the travel time is measured. Its absence means that no measurement was carried out (for example if there were too many interfering signals).
- The horizontal dotted bar shows the measurement threshold. The measurement is carried out on the first movement to 0 of the cycle which crosses this threshold.
- On the bottom left is shown the travel time difference of the ultrasounds (does not include  $\Delta T_0$ ).

## 5.5 NORMAL configuration

**Comment:** The following description will be restricted to the additional functions of normal configuration as compared with simple configuration. The common base already explained in the simple mode section is not repeated in this section.


### 5.5.1 "Pipe/fluid configuration" menu

#### 1) Memory


The memory time is the time, given in seconds, for which the measurement is stored in memory when a measurement is lost (echo loss).

This memory time is used in particular to avoid untimely actions from the instrumentation and control part of the installation.

Two situations may arise:



Case no. 1: Duration of the measurement loss less than the memory time. In this case, the flow meter holds the last measurement until a new valid measurement is obtained.



Case no. 2: Duration of the measurement loss greater than the memory time. The flow meter extends the last measurement until the elapsed time exceeds the memory time. Then the flow metering system faults itself if there are still no new valid flow rate measurements.


## 2) Filter

The flow measurement can be filtered so as to make the measurement results more legible.

```
----- PIPE A-----  
Nbr of chords = 2  
-----General-----  
Q Unit      = m3/h  
Memory      = 10s  
Filter       = 10s  
DeltaQ Fil. = 5.000m/s  
-----Graph-----  
Q Period    = 1s  
Q Qmin      = 0.0  
Q Qmax      = 10.0
```

This feature must be used when the flow is extremely chaotic and an average for the flow needs to be produced in order to view its evolution.

The diagram below illustrates the effect of the filtering in the event of a very versatile and turbulent measurement:



The filter time constant, given in seconds, defines the "force" of the filtering: following a flow rate step (quick opening of the isolation dam), the value measured reaches the final value at 1% after the time constant.

To adjust this time constant, a simple rule involves taking as the time constant a value equal to two or three times the foreseeable duration of any interference: for example, if you wish to avoid seeing flow variations quicker than every 20 seconds, give the time constant a value of 40 or 60 s.

However, you must ensure that the time constant is not too large, since this would risk masking significant events.

### 3) Delta T0 and Auto zero

----- PIPE A -----		----- PIPE A -----	
-----Chord 1-----		-----Fluid-----	
Probe	= SE1515/10	Product	= water (20 C)
Mounting	= U	C0	= 1482m/s
		DeltaC	= 388m/s
Ext.Coef.=	AUTO.	KH Type	= AUTO.
DeltaT0	= 0.00ns	Viscosity=	1.00Cst
Seek Gain	= 30dB	Roughness	= 0.10mm
Gain Max	= 96dB	Reynolds C=	2800
		LBR	= 3.000
		-----Calibration-----	
		CutOff Q.=	0.01m³/h
		Autozero	= NO

The DeltaT0 field is used to correct installation errors. For example, it is possible to compensate for a bias due to an incorrect position of the probes by adding to DeltaT0 the value required in order to rectify it.

It is also possible to launch an automatic determination mode for the Delta T0 by selecting a time (30 s, 1 min, etc.) in "Autozero". **Warning**, before doing this ensure that the pipe is definitely at rest.

### 4) C0 and Delta C

With a "normal" configuration, it is possible to select a fluid and its associated celerity from a non-exhaustive list. The celerity relating to the selected fluid is displayed automatically in the C0 field. If a fluid not shown in the list, you can select "Product = OTHER" and define a special C0 value (the C0 field becomes editable).

----- PIPE A -----	
-----Fluid-----	
Product	= water (20 C)
C0	= 1482m/s
DeltaC	= 388m/s
KH Type	= AUTO.
Viscosity=	1.00Cst
Roughness	= 0.10mm
Reynolds C=	2800
LBR	= 3.000
-----Calibration-----	
CutOff Q.=	0.01m³/h
Autozero	= NO

The Delta C is used to indicate to the flow meter the variation in the speed of the sound and therefore the "search" area for the ultrasound echo. To use this variable, it is preferable to use the standard settings and launch the echo display (see the "Echo display menu" section).

If the echo is outside the search window, you can:


- change the C0 to re-centre the window,
- change the Delta C to widen or shorten the search window.

If the echo is on the right, the value of C must be lowered.

Conversely, if the echo is on the left, the value of C must be increased.

## 5) KH

The hydraulic coefficient KH is used with external probes (clamp-on or diametric intrusive). It is used to determine the speed throughout the cross-section of the pipe from the average speed over a diameter. Its value therefore depends on the speed and the flow conditions (laminar or turbulent).



(a) Laminar: The fluid veins are parallel to the axis of the pipe. This results in a parabolic speed profile.

(b) Turbulent: The fluid veins are not parallel to the axis of the pipe. This results in a "rectangular" speed profile.

The KH can be calculated automatically ("Type KH = AUTO") or set manually.

```

----- PIPE A-----
----- Fluid-----
Product =
      water (20 C)
CØ      = 1482m/s
DeltaC  = 388m/s
KH Type = AUTO
Viscosity = 1.00Cst
Roughness = 0.10mm
Reynolds C = 2800
LBR      = 3.000
-----Calibration-----
CutOff Q. = 0.01m³/h
Autozero  = NO
  
```

In automatic mode, the viscosity of the fluid and the roughness of the inside of the pipe must be defined.

In manual mode, you can define the KH yourself (if you have a good understanding of the flow rate in your pipe).

## 6) Deletion rate (Qeff)

The deletion rate is the flow rate below which the flow meter will display 0. This gives you a clear indication of a flow rate considered to be null.

## 5.6 ADVANCED configuration

**Comment:** The following description will be restricted to the additional functions of advanced configuration as compared with the configurations defined previously (simple and normal). The common base already explained above in this document is not repeated in this section.

### 5.6.1 "Pipe/fluid configuration" menu

#### 1) Delta V filtering

When a filter has been activated, it is possible to request that the flow meter disables the filter if the measurement changes very quickly. This provides a filter which is sufficient to comfortably see the change of the measurement and to retain reactivity while not filtering large variations in velocity:

```
----- PIPE A-----
Nbr of chords = 2
----- General-----
Q Unit = m³/h
Memory = 10s
Filter = 10s
DeltaV Fil. = 5.000m/s
----- Graph.-----
Q Period = 1s
Q Qmin = 0.0
Q Qmax = 10.0
```


#### 2) Material of the pipe wall

In Advanced mode, you can define the wall through 3 different materials/layers. If no material shown in the list is the same as that making up your pipe, select "OTHER": you will then be able to define the appropriate celerity for the sound.

```
----- PIPE A-----
----- Tube-----
Ext.Diam. = 587.21mm
Ext.Circ. = 1844.77mm
----- Wall-----
Material 1 = COPPER
Thick. 1 = 9.25mm
Material 2 = NONE
Material 3 = NONE
```

### 3) Laminar/turbulent transition

We have previously mentioned in this document the flow type (laminar or turbulent) for the calculation of KH. In "Advanced" configuration mode, you can change part of the KH calculation mode by defining the laminar/turbulent transition point.



----- PIPE A -----	
----- Fluid -----	
Product	= water (20 C)
C0	= 1482m/s
DeltaC	= 388m/s
KH Type	= AUTO.
Viscosity	= 1.00Cst
Roughness	= 0.10mm
Reynolds C	= 2800
LBR	= 3.000
----- Calibration -----	
CutOff Q.	= 0.01m³/h
Autozero	= NO

The transition between the two types of flow varies according to the case and the measurement points. It is possible to change the configuration of this transition within the flow meter by changing the critical value of the Reynolds number (Reynolds number at which the flow transition occurs) and width LBR of the transition.

**Comment:** The lower the LBR, the more abrupt the transition.

### 4) Seek gain and Gain max

The gain is the parameter which determines the amplification of the ultrasonic signal required for the flow meter to take a measurement. If the flow meter needs to increase the gain, this means that the ultrasonic signal received is very weak. The poorer the quality of the signal, the greater the gain and the more difficult it is to measure the flow.

----- PIPE A -----	
----- Chord 1 -----	
Probe	= SE1515/10
Mounting	= U
Ext.Coeff.	= AUTO.
DeltaT0	= 0.00ns
Seek Gain	= 30dB
Gain Max	= 96dB

Using the maximum gain setting, you can reject measurements if the gain exceeds the value entered in the flow meter.

**Important:** You are strongly advised to contact Ultraflux before modifying these settings.


### 5) Weighting coefficients of the chords

The chord weighting coefficient is only useful for parallel intrusive probes. It is a correction factor for each chord applied to the speed before the overall calculation of the flow rate in the pipe from the weighted speeds of all the chords:

$$Q = \frac{\pi D^2}{4} * \sum C_i * V_i \quad \text{where } C_i \text{ are the weighting coefficients and } V_i \text{ the measured ultrasound speeds.}$$

These coefficients are fundamental for a measurement using parallel chords. They are predetermined according to the number of chords:

	a / R	C <sub>i</sub>
2 chords	+ and - 0.5	0.5
4 chords	+ and - 0.3090	0.3618
	+ and - 0.8090	0.1382



Please feel free to contact Ultraflux to determine the value of the weighting coefficients.

### 5.6.2 "Linearisation settings" menu

One last action possible on the flow is the linearisation of the result. Depending on the flow, the flow is corrected by X% based on a pre-defined table:

Q ref= -QA			Q ref= +QA		
θ (m³/h)			θ (m³/h)		
Coef. 0	%	= 1.0000	Coef. 0	%	= 1.0000
Coef. 10	%	= 1.0000	Coef. 10	%	= 1.0000
Coef. 20	%	= 1.0000	Coef. 20	%	= 1.0000
Coef. 30	%	= 1.0000	Coef. 30	%	= 1.0000
Coef. 40	%	= 1.0000	Coef. 40	%	= 1.0000
Coef. 50	%	= 1.0000	Coef. 50	%	= 1.0000
Coef. 60	%	= 1.0000	Coef. 60	%	= 1.0000
Coef. 70	%	= 1.0000	Coef. 70	%	= 1.0000
Coef. 80	%	= 1.0000	Coef. 80	%	= 1.0000
Coef. 90	%	= 1.0000	Coef. 90	%	= 1.0000
Coef. 100	%	= 1.0000	Coef. 100	%	= 1.0000

The parameter Q ref defines the maximum flow used for the linearisation. The points of the table are then defined as a percentage of this maximum.

The rectifier coefficient must be defined by the user:

- A coefficient of 1 does not change anything in the result.
- A coefficient of 0.8 reduces the value of the flow by 20% at this point, etc.

There are two tables, one for positive flows and one for negative flows.

### 5.6.3 "Advanced settings" menu

#### 1) Simulation mode

```
----- PIPE A-----  
Function = Measure
```

The flow meter can be used:

- in Measurement mode (normal operation of the flow meter),
- in Flow simulation mode.

Enter the value of the flow required and the sine wave (as a percentage) applied around this value.

**Comment:** A modulation of 0% keeps the flow velocity constant. A modulation of 100% fluctuates the simulated flow between 0 and 2 times the indicated value.

#### 2) Special probes

It may be necessary in certain cases to define a probe which is not referenced in the list of Ultraflux probes. Before using this option, you are strongly recommended to contact Ultraflux.

To use probes other than those of Ultraflux, use the "special probes" function.

```
-- SPECIAL PROBES --  
-----Probe SA-----  
T0   = 0.00µs  
F    = 2Mhz  
Angle= 0.00  
Text =SA  
  
-----Probe SB-----  
T0   = 0.00µs  
F    = 2Mhz  
Angle= 0.00  
Text =SB
```

T0 represents the dead time of the probe.

F represents the frequency of the probe.

Angle relates to the angle of the ultrasound probe. For an open channel probe, the angle is always 0.

Text is used to identify the special probe in the list of references of accessible probes.

#### 3) US & TRT processing

These settings allow the Ultraflux teams to adapt the operation of the flow meter to a specific case. You must consult us before any modification of these settings.

### 5.6.4 "Firmware update" menu

This option is used to update the flow meter without needing to dismount it. Consult us prior to using this option.

## 5.7 "Measurement" mode


The flow meter has measurement pages (different values are displayed on successive pages) including a flow graph.

### 5.7.1 Pages available

The Measurement screens provide a large amount of information: to scroll through and access the pages, use the ▲ and ▼ keys.


The same information is displayed for each of the chords of the application:

#### 1) Flow



This page displays the flow measured with the unit.


#### 2) Pipe measurements



This page displays the data relating to the flow: flow rate, measured Reynolds number, calculated KH, average speed in the pipe, etc.

#### 3) Specific information relating to the chords

These pages (which depend on the number of chords) provide information on the specific measurements for a chord:



- average time (average of the time for the upstream-downstream journey and the time for the downstream-upstream journey),
- delta T (difference between the upstream-downstream journey time and the downstream-upstream journey time),
- measurement gain (the higher the gain, the more difficult it is to obtain a measurement),
- IQ quality index (100% indicates a very good measurement, 0% indicates that the measurement is not possible).

#### 4) Totalizers

```

-----TOT1(QA  +) I27
399654510      100 m³

```

## 8) Distance between probes

```
----- PIPE A-----  
-----Chord1-----  
Probe      = SE1515/10  
Mounting   = U  
D.Probe    =      158mm  
  
-----Chord2-----  
Probe      = SE1515/10  
Mounting   = U  
D.Probe    =      158mm
```

These pages (which depend on the number of chords) provide the reference of the associated probes for each chord.

For external probes, this screen also shows:

- the installation type (direct/reflex),
- the required distance between the probes.

## 9) Flow graph

The flow graph is a screen which shows the changes in a particular magnitude in the form of a curve.

### 5.7.2 Verification of the quality and consistency of the measurement

The information from the various pages in the "measurement" mode allow you to check whether your measurements are consistent.

The gain and IQ (Quality Index) values also provide you with information on the quality of your measurement.

## **CHAPTER 6: FUNCTION ENGINE**

## 6.1 Principle

Each Uf 811 includes a miniature PLC. This PLC allows Ultraflux to easily install additional features for this flow meter.

On request, Ultraflux can quickly integrate a new feature for your Uf 811.

## 6.2 Application examples

### 6.2.1 Water temperature calculation

The water temperature can be determined from its celerity (via a calculation).

You will find in the appendix the polynomial used to determine the temperature of the water based on the celerity measured by our flow meters.


The function engine allows us to carry out this calculation internally in the flow meter.

### 6.2.2 Calorimetry

It is possible to measure the heat flow of an installation.

If a cold temperature measurement and hot temperature measurement is combined with the flow rate calculated by the flow meter, the heating power expended can be measured.

The diagram below shows a typical measuring point for this application:



The following graph illustrates a measurement result typical of the application of calorimetry, the values displayed being:

- the temperature difference between the probes,
- the instantaneous heating capacity,
- the kWh meter.

## **CHAPTER 7: PC SOFTWARE**

## 7.1 Introduction

The PC software is used to configure the flow meter using a PC, rather than accessing the parameters using the keypad of the flow meter.

It is used in particular:

- to define all settings for the application,
- to monitor, in real time, the measurement parameters (flow, average velocity, speed of sound and gain for each chord, etc.),
- to save the measurement or settings data in a file for later consultation,
- to download, using the serial link or USB, the flow meter operation settings, the measurement data, the logger,
- to print the displayed data,
- to transfer the measurement and logger data to a spreadsheet program.

The minimum PC configuration required is a PC with a Windows version later than Windows XP.


### 7.1.1 Installing and running the software

To install the software:

1. Run the Setup.exe installation program included on the CD-ROM,
2. Select the language to use for the installation and for displaying the screens,
3. Using the Browse button, specify the software installation path (by default C: \ Program Files \ Ultraflux \ [PC software corresponding to your flow meter].x, with x designating the version no.).

**Comment:** For an identical reinstallation of the program (for example in the event of damage to the execution file) or to uninstall it, select the program from the list of installed programs (Start / Settings / Configuration panel / Add/Remove programs) and click the Add/Remove button.

A window asks you which action you wish to carry out: Change (function not available for the software, since it only contains a single component), Repair or Remove.

The program is run by double-clicking the icon  associated with the software and placed on the desktop, or by selecting the program via Start \ Programs \ Ultraflux \ software corresponding to your flow meter.

The options proposed by the 4 main menus are:

- "File" menu – to:
  - Open a measurement, configuration or logger file (using the *"open"* command),
  - Create a configuration file (using the *"new"* command),
  - Close the program (using the *"exit"* command).
- "Dialogue" menu (with the flow meter) – to:
  - Call up the measurement window,
  - Call up the settings window,
  - Change the access code,
  - Download logger data from the flow meter to the PC,
  - View the echo display,
  - Save all settings of the flow meter.
- "Configuration" menu – to:
  - Configure the PC software,
  - Load the configuration file,
  - Save the configuration file.
- "About" menu – to:
  - Obtain information on the version of the PC software.

### 7.1.2 Connecting the flow meter to the PC

To connect the Uf 811 to the PC, you must connect the lead provided (serial link or USB cable). The exchanges are made in the JBus/ModBus protocol, the PC being the master and the Uf 811, identified by its number, being the slave.

### 7.1.3 Home page

When run, the software displays the following window:




This window contains 4 main menus:

- "File",
- "Dialogue",
- "Configuration",
- "About".

First open the Configuration menu to define the settings relating to your application.

#### 7.1.4 Configuration window



The window opened by the Configuration menu is used in particular to select the display language and to define the path of the software used to work with the data (Excel by default, if this is installed on your computer).

It also includes a **"Autosearch" button** used to automatically detect the presence of an Ultraflux flow meter.

**Comment:** To use the serial link, the transmission speed can be set from 300 to 115,200 bauds, the fastest speed being preferable, especially for data-logger downloads.

#### 7.1.5 Icons

Icons are displayed at the bottom of each window of the "Dialogue" Menu (with the flow meter).



This icon in the form of a disk runs the save procedure. The software then asks you for the name of the folder in which to save. You can then read, print or handle in Excel (or the data processing software) these records using the command File / Open / [save name].

**Comment:** When measuring, once the saving process has started ("Save" button), the data is saved at the pace established by the period entered in the configuration menu of the software, up to the set time. When Time = 0, it is stopped manually.



This icon is used to print all data displayed on the screen.



This icon launches the data transfer procedure from the PC to the flow meter.

### 7.1.6 File menu

The File menu allows you to open a saved file ("Open" command), or prepare a settings file offline ("New" command). Once the file is saved, you can export it to a Uf 811.



### 7.1.7 Measurement window

The measurement window is opened using the Dialogue/Measurement command.



#### 1) List of available tabs

The (measurement) window contains the following tabs:

- "General" tab: contains the general information on the measurement.
- "QA" (flow rate) tab: contains the general information concerning the measurement channel.
- "Input/output" tab: contains the general information on the inputs/outputs.
- "Function" tab (optional): contains configuration data for the function engine if this is used (this tab only appears if at least one output from the engine is configured).

## 2) "General" tab

This tab displays the main information about the measurement: graphic display of the measurement, instant values of the flow rate and flow velocity, totalizers.

**Measurement**

General | QA | Function | Input-output 01-04

02/05/2012 - 17:01:23  
Defaults

Totalizer(s)  
Tot. 1 : QA (+) 399737962 x 100 m3

QT 19.49 m3/h


QA 19.49 m3/h 0.021 m/s

10.0 m3/h  
0.0 m3/h

Version  
Unit Name UF8xx  
Type 2 Pipes  
Firmware 26-15-05-A(862\*) 00-72-05-K.d(860\*)  
Serial Nbr. 40/11/0069 Hardware MK6-G

### 3) "QA" tab (flow rate)


This tab displays the main information concerning the measurement channel: graphic display of the measurement, instant values of the flow rate and flow velocity and KH; information related to the measuring chords.



**Comment:** There are as many tabs as there are pipes configured.

#### 4) "Inputs/outputs" tab

This tab displays the information concerning the inputs/outputs of the flow meter.



### 7.1.8 Settings window

#### 1) List of available tabs

*This is a complete list showing all the tabs available in Advanced configuration mode. Simple or normal configuration reduces the number of tabs you can access.*

The configuration window, opened using the Dialogue/Settings command, contains the following tabs:

- In the "General" drop-down menu
  - "General" tab: selection of the flow meter display language (and name of the flow meter defined during the installation).
  - "Logger" tab: description of the operation of the logger.
  - "Totalizer" tab: definition of the operation of the totalizers.
  - "Function" tab: definition of the engine input constants accessible to the user (when a function is located in the engine).
  - "Advanced" tab: definition of the Advanced operating mode.
  - "Inputs/outputs" tab: definition of the configuration of the inputs and outputs.

- In the "Control" drop-down menu
  - "Control" tab: flow unit, time constants, flow graph settings, display options, etc.
  - "Chord" tab: definition of the probes, positions of the chords, etc.
  - "Advanced chord" tab: definition of specific codes used to fine-tune the behaviour of the flow meter (contact Ultraflux before modifying these settings).
  - "Linearisation" tab: flow rate linearisation coefficient.



Once the settings are completed, upload the configuration to the flow meter by clicking this button.

**Comment:** On opening the settings window, the configuration loaded in the PC is the current configuration of the flow meter.

## 2) "General" tab (in the "General" drop-down menu)

The settings window is used to configure the flow meter from the PC. As with the keypad, you can choose the level of complexity using the command: General/Application Selection/Level = Simple, Normal or Advanced.

The screenshot below shows an example of an Advanced mode configuration. All settings displayed below have been described previously in this document.

01A - Relay output	01B - Relay output	02A - Input 4 - 20 mA	02B - Input 4 - 20 mA
Function : Totalizer	Function : Fault	Function : Simulation	Function : Off
Value : General / Tot. 1	Value : General / Status	4 mA : 0.350	
Step : 50 ms	Normally : Open	Range : 4.000	
		Simulation value : 1.875	
		Value : 1.875	

03A - Input 0 - 10 V	03B - Input 0 - 10 V	04A - Analog Output	04B - NC
Function : Off	Function : On	Function : 4-20 mA	
	0 V : 0.000	Value : Chanel - A / Velocity	
	Range : 0.061	4 mA : 0.000	
	Filter : 10 s Memory : 60 s	Range : 16.000	
	Value : 0.000	Defaults : 3.600 mA	

The software allows the date and time of the Uf 831 to be synchronized with those of the host PC: select the option "Synchronise with PC time" before saving the settings on the flow meter.

It is important to correctly set the date and time in order to time stamp the records (country, summer/winter time).

### 3) "Logger" tab (in the "General" drop-down menu)

The screenshot below shows an example of settings in Advanced mode. All the settings displayed below have been described previously in this document (see section 5.4.5).

The screenshot shows the 'Logger' tab in the 'Settings - Device connected' window. The 'General' dropdown menu is selected. The 'Logger' tab is active, showing various settings for logging data. The 'Reset logger' is set to 'No', 'Logger Mode' is 'Cyclic', and 'Nbr. of parameters' is '5'. The 'Period logger' is '1 mn', 'Max nbr. of record' is '179476', and 'Range' is '4 m, 0 d, 15 h'. The 'Logger on change' is set to 'Yes'. There are three rows of settings for logging on change: N° 1: Pipe A, Q, 1.0 %; N° 2: Pipe A, Velocity, 1.0 %; N° 3: Pipe A, Q, 0.0 %. Below these, there are five rows of settings for logging: N° 1: General, Status; N° 2: Pipe A, Q, Average; N° 3: Pipe A, Sp. Sound, Average; N° 4: Pipe A, Velocity, Average; N° 5: Pipe A, Status. The bottom of the window shows a status bar with a printer icon, a red arrow icon, a red heart icon, and a blue disk icon.


### 4) "Totalizers" tab (in the "General" drop-down menu)

The screenshot below shows an example of settings in Advanced mode. All the settings displayed below have been described previously in this document (see section 5.4.3).

The screenshot shows the 'Totalizers' tab in the 'Settings - Device connected' window. The 'General' dropdown menu is selected. The 'Totalizer(s)' tab is active, showing settings for four totalizers. Totalizer 1 has 'Direction' set to '+', 'Value' set to 'QA', 'Pulse' set to '100 m3', and 'Reset' set to 'No'. Totalizer 2 has 'Direction' set to 'Off'. Totalizer 3 has 'Direction' set to 'Off'. Totalizer 4 has 'Direction' set to 'Off'. The bottom of the window shows a status bar with a printer icon, a red arrow icon, a red heart icon, and a blue disk icon.

5) "Inputs/Outputs" tab (in the "General" drop-down menu)

The screenshot below shows an example of settings in Advanced mode. All the settings displayed below have been described previously in this document (see section 5.4.4).



You can choose whether or not to activate the Totalizer, Logger and Input/output functions resources.

## 6) "Control" tab (in the "Control" drop-down menu)

The screenshot below shows an example of settings in Advanced mode. All the settings displayed below have been described previously in this document (see section 5.4.2).

The screenshot shows the 'Settings' window with the 'Pipe - A' tab selected. The 'Control' section is active, displaying various parameters for the pipe and flow. The 'Pipe' section includes 'Ext. Diameter' (587.21 mm), 'Material' (Copper), 'Thickness' (9.25 mm), 'C. Material' (2260 m/s), and 'Material' (No). The 'Flow' section includes 'Q Unit' (m3/h), 'Filter' (10 s), 'Filter DeltaV' (5.000 m/s), 'Memory' (10 s), and 'Cut OFF Q' (0.01 m3/h). The 'Product' section includes 'Product' (water (20°C)), 'C0' (1482 m/s), 'Delta C' (388 m/s), 'Kh' (Automatic), 'Viscosity' (1.00 cSt), 'Roughness' (0.10 mm), 'Critical Reynolds' (2800), and 'L.B.R.' (3.000). The 'Graph' section includes 'Min' (0.0 m3/h), 'Max' (10.0 m3/h), and 'Step' (1 s).

## 7) "Chord" tab (in the "Control" drop-down menu)

The screenshot below shows an example of settings in Advanced mode. All the settings displayed below have been described previously in this document (see section 5.4.2).

The screenshot shows the 'Settings' window with the 'Pipe - A' tab selected. The 'Chord' section is active, displaying parameters for the number of chords and probe settings. The 'Number of chords' is set to 2. The 'Coef. Ext. P.' is set to Automatic. The 'Probe' section includes 'Probe' (SE 1515-10) and 'Probe mounting' (V). The 'DeltaT0' is set to 0.00 ns. The 'Search Gain' is set to 30 dB. The 'Max Gain' is set to 96 dB.

**Note:** It is possible to enter in the flow rate calculation a chord external to the converter (for example, a Doppler velocity measurement). The settings to be defined for this chord are the same as those for the internal chords, but the following must also be defined:

- the internal chord associated with the external chord: when the internal chord is faulty, the external chord takes over.
- the input module which will serve as a velocity measurement: a 4-20 mA module may be used to recover a Doppler velocity.

The main advantage of this virtual chord lies in being able to measure the flow using several measurement methods.

#### 8) "Linearisation" tab (in the "Control" drop-down menu)

The screenshot below shows an example of settings in Advanced mode. All the settings displayed below have been described previously in this document (see section 5.6.2).

The screenshot displays the 'Settings - Device connected (Changed)' window with the 'Pipe - A' tab selected. The 'Linearization' section is active, showing two columns of settings for 'Linearization (-)' and 'Linearization (+)'. Each column has a 'Ref. Q' field set to '0 m3/h' and a list of coefficients from 0% to 100%, all set to '1.000'. There are '=1' buttons at the bottom of each column. The window title bar indicates 'Settings - Device connected (Changed)' and the tab is labeled 'Pipe A'.

## 7.2 Archiving, processing and printing of saved files

You can save the settings for the flow meter and the associated measurement results.

These are complete records of the measurements and conditions observed, which are a useful addition to those of the data logger. The files are named with an extension [\*.mes].

These records on the screen are presented in the same way as the Measurement dialog (see section 5.8), with a few additional icons at the bottom of the screen.

Use the following buttons to browse or select the records:



Use the following button to print the records:



If you have saved a sequence (Configuration/General/Save file/Period and Time) command), you will be able to process this data with the software used for data handling (Excel by default, if this is installed on your computer). A macro for Excel is provided.

Data processing is called by clicking the following button:



In the windows opened, confirm the name of the file to be processed, and accept the macro. You should first specify the security level of this macro.

The results from the measurement pages are automatically arranged in the columns and rows of Excel, and the flow and velocity curves are produced. You can then freely modify this data.

## 7.3 Settings files

The Uf 811 has 11 spaces in its free memory for the storage of configurations (see part 5.4.1): you can therefore recall or save your selections.

**Important:** only the first 5 locations are accessible from the PC software, the other 6 may only be accessed via the converter.

## **Appendix I: Characteristic echo signals**


# The most common echo signals

The display of the echo signal is not essential, but does facilitate the implementation of the measuring point. It also allows the origin of a problem to be detected.

The positioning and orientation of the probes are correct when the amplitude of the echo is at its maximum and the echo is rising rapidly, without too much distortion (deformations).

The following figures show the most commonly observed echo signals:

- Ideal signal: quick rise well above the detection threshold.



**Comment:** The signals observed are often longer than the one shown above. This is completely normal, the important criterion being the velocity of the signal rise above the threshold.


- Slowly rising signal:



- Signal distorted by an incorrect positioning of the probes:



- Presence of noise (acoustic interference)



**Comment:** For the last three cases, a weak signal (gain greater than 50 dB) may mean that the probes require realignment or maintenance (pollution on the surface of the probe).

- Presence of electromagnetic interference




**Comment:** in this case, move the cables (in particular the probe cables) away from the power cables. Check the ground connections and the shielding.

## **Appendix II: Speed of sound in water**

## Sound propagation velocity in water

t (°C)	C (m/s)	t (°C)	C (m/s)
0	1422.8.	30	1506.4.
5	1426.5.	35	1520.1.
10	1447.6.	40	1529.2.
15	1466.3.	45	1536.7.
20	1482.7.	50	1542.9.
25	1497	—	—

Approximate value:  $C = 1557 - 0.0245 \cdot (74 - t)^2$



## **Appendix III Troubleshooting**

III.1 Diagnostic indications

III.2 Description of fault bits

III.3 Fault grid

### III.1 Diagnostic indications

Certain factors may lead to a degradation of the measurement. The following diagnostic indications will help you to resolve any problems which may occur.

- **The message "Velocity faults" is permanently displayed**

Possible causes:

- Probes different to those indicated in the settings. Incorrect programming of the Daxe and L settings.
- Incorrect connection of the probes. A probe may have been disconnected.
- Presence of a solid body between the probes.
- Chords out of the water.
- Probes incorrectly positioned with regard to each other.
- Probes excessively clogged.
- Fluid too absorbent, too much slurry, excessively aerated. Contact us and we will work with you to find the best solution.
- Probes defective or Uf 811 malfunctioning. Contact us if your checks result in this conclusion.

- **The message "Flow faults" appears intermittently**

The intermittent message "Flow faults" may be due to a weak echo, resulting in a high gain.

The possible causes are, to a lesser extent, identical to those of the "Velocity faults" message (see above), and in particular:

- Probes misaligned,
- Probes clogged,
- Fluid absorbent, or slurry, or aerated.

**Comment:** A simple way of masking intermittent measurement faults and increasing the memory storage time (see section 5.5.1).

- **The measurement differs from the predicted flow**

Actions to take

- Check that the probes are far enough away from hydraulic disturbances.
- Check the precise dimensions of the section of the pipe or the channel at the location of the measurement and the position of the probes.
- Have faith in your Uf 811.

- **The message "relay overflow" appears permanently or intermittently in the case of a relay output configured in totalizer mode**

Cause:

- Too many pulses output within the allocated time.

Actions to take

- Adapt the pulse weight and/or the width based on the flow of your application (see the "Totalizer" section 5.4.4 - point 5).

- **The message "open loop" appears permanently when setting a current output**

Cause:

- Break in the loop.

- **The message "outside limits" appears permanently or intermittently when setting an analogue input**

Cause:

- Current or voltage outside the range of use.

### III.2 Description of fault bits

In general, a bit set to 1 means that there is a fault present and 0 means there is no fault. The numbering of the bits **starts at Zero!**

Two bits have the same meaning on each fault field:

BIT No.	FUNCTION NAME	DESCRIPTION
30	Fault	The measurement is faulty.
31	Not valid	Measurement is not possible, but the situation is not abnormal (1).

(1) For example, all probes are out of flow.

#### General fault

BIT No.	FUNCTION NAME	DESCRIPTION
4	Logger	At least one reading in the logger is not consistent.
18	Function engine	A problem has occurred on one of the outputs of the function engine. This fault is used to identify a calorimetry problem for example.
19	Ultrasound configuration	The ultrasonic board has a configuration problem.
20	Alarm C	A peripheral system has a fault.
21	Alarm B	Maintenance is required on the flow meter.
22	Alarm A	The flow meter has a general fault.
23	Access code	The maximum number of unlocking attempts has been reached. Please wait before trying again.
24	Configuration access	The configuration has been changed or the device is in echo display mode.
25	Power supply	The power supply has been cut off and restored.
26	Inputs/Outputs	Fault on an input/output module.
27	Internal clock	The clock time must be set correctly.
28	Qb	Fault on the Qb pipe.
29	Qa	Fault on the Qa pipe.
30	QT	Fault on the total flow.
31	QT not valid	Total flow invalid.

## Pipe fault

BITS No.	FUNCTION NAME	DESCRIPTION
0	Velocity1	Chord 1 velocity faulty.
1	Velocity2	Chord 2 velocity faulty.
2	Velocity3	Chord 3 velocity faulty.
3	Velocity4	Chord 4 velocity faulty.
4	Velocity5	Chord 5 velocity faulty.
5	Velocity6	Chord 6 velocity faulty.
6	Velocity7	Chord 7 velocity faulty.
7	Velocity8	Chord 8 velocity faulty.
16	General velocity	All velocities are faulty.
17	General level	All levels are faulty.
18	Height velocity	The height velocity law or the automatic regression is activated.
30	Fault	Fault on a velocity.
31	Not valid	Velocity not valid.

## Input/output modules fault

BITS No.	FUNCTION NAME	DESCRIPTION
0	On relay A output metering	Relay A cannot output the number of pulses required based on the programmed period.
1	Relay A output outside range	Relay A cannot output the required frequency based on the programmed range.
2	On relay B output metering	Relay B cannot output the number of pulses required based on the programmed period.
3	Relay B output outside range	Relay B cannot output the required frequency based on the programmed range.
4	Current A output loop open	Current loop open.
5	Current A output value outside range	The value of current A is outside the authorized range.
8	Value outside range input PT100/1000	The temperature measurement of PT100 A is outside the authorized range.
12	Current A input value outside range	The measurement of current A is outside the authorized range.
14	Current B input value outside range	The measurement of current B is outside the authorized range.
16	Voltage A input value outside range	The measurement of voltage A is outside the authorized range.
18	Voltage B input value outside range	The measurement of voltage B is outside the authorized range.

**Chord fault**

BIT No.	FUNCTION NAME	DESCRIPTION
22	Chord immersion	Chord submerged.
26	Overspeed/underspeed	Chord overspeed/underspeed.
29	Flow calculation	Chord taken into account in the flow calculation.
30	Fault	Fault on a chord.
31	Not valid	Chord not valid.

**Function fault**

BIT No.	FUNCTION NAME	DESCRIPTION
30	Fault	Function output fault.

### III.3 Fault grid

There are three types of alarm:

- Alarm A: General fault,
- Alarm B: Maintenance requirement / Degraded mode,
- Alarm C: Alarm on peripheral system.

Using the PC software, you can find the detail of each of these alarms with the key word displayed in the fault window (see the chapter dedicated to the PC software).

The explanation of these key words is given below:

#### Alarm A:

KEY WORD	EXPLANATION
firmware	There is a recognition problem for the internal software of the flow meter. Contact Ultraflux.
EEprom	The non-volatile memory is faulty, measurement is impossible. Contact Ultraflux.
Function	The function engine has an execution bug. Check the inputs to the function engine. If the problem persists, contact Ultraflux.
Com .ER	There is a programming problem with the two DSP processors. Turn the flow meter off, and then back on. If the problem persists, contact Ultraflux.
Bad software	The internal software of the flow meter is not compatible with the type of flow meter programmed (Full Pipe, Open Channel, ISD, PSD, etc.). Contact Ultraflux.
Q	Fault on the flow.

#### Alarm B:

KEY WORD	EXPLANATION
velocity	Fault on one of the eight velocities.

#### Alarm C:

KEY WORD	EXPLANATION
Dataflash	The non-volatile memory is faulty; measurement is possible but not archiving by the logger. Contact Ultraflux.
logger	The logger data cannot be used or is corrupt. Contact Ultraflux.
h/w I/O	One of the inputs/outputs is no longer responding. Contact Ultraflux.
i/o	One of the inputs/outputs is incorrectly configured. Contact Ultraflux.
clock	The clock time must be set correctly.

## **Appendix IV: Link protocol of the Uf 811**

IV.1 Serial link characteristics

IV.2 Reading of N words (with  $N \leq 125$ )


IV.3 Modbus/Jbus table

IV.4 CRC16 calculation algorithm

## IV.1 Serial link characteristics

The characteristics of the serial link to be used are as follows:

- Protocol used: Modbus,
- Transmission speed: from 300 to 115200 bauds,
- Number of bits: 8,
- Parity: None,
- Number of stop bits: 1.



Where: 
$$V = (-1)^S * \left(1 + \frac{M}{2^{23}}\right) * 2^{(E-127)}$$

Example: float value = \$40, \$21, \$00, \$40

$$S = 0 ; E = , $80 = 128d ; M = 210040 = 2162752d$$

$$V = (-1)^0 * \left(1 + \frac{2162752}{2^{23}}\right) * 2^{(128-127)} = 2.5151640259$$

For FLOAT type information, it must be possible to read two consecutive words (or 4 bytes). The format complies with the IEEE standard.

For LONG type information, two consecutive words (or 4 bytes) must be read.

## IV.2 Reading of N words (with $N \leq 125$ )

The function code for reading N words is 3.

### Request

Data	Slave no.	3	address 1st word	number of words	CRC16
Size	1 byte	1 byte	2 bytes	2 bytes	2 bytes

### Response

Data	Slave no.	3	number of bytes read	value 1st word	....	value last word	CRC16
Size	1 byte	1 byte	1 byte	2 bytes	....	2 bytes	2 bytes

### IV.3 Modbus / Jbus table

(1): full pipe only  
(2): open channel only


PARAMETER NAME	Type	Pipe/Channel A		Pipe/Channel B	
		JBUS Hex address	JBUS Dec address	JBUS Hex address	JBUS Dec address
<b>Logger</b>		<b>0200</b>	<b>512</b>	<b>0400</b>	<b>1024</b>
No. Variables Per Line	USHORT	0200	512	0400	1024
No. Completed Lines	ULONG	0201	513	0401	1025
Max. Line No.	ULONG	0203	515	0403	1027
Period (seconds)	ULONG	0205	517	0405	1029
		0207	519	0407	1031
<b>Totalizers</b>		0207	519	0407	1031
Totalizer1 value	ULONG	0207	519	0407	1031
Totalizer1 Weight	USHORT	0209	521	0409	1033
Totalizer1 Unit	USHORT	020A	522	040A	1034
Totalizer2 value	ULONG	020B	523	040B	1035
Totalizer2 Weight	USHORT	020D	525	040D	1037
Totalizer2 Unit	USHORT	020E	526	040E	1038
Totalizer3 value	ULONG	020F	527	040F	1039
Totalizer3 Weight	USHORT	0211	529	0411	1041
Totalizer3 Unit	USHORT	0212	530	0412	1042
Totalizer4 value	ULONG	0213	531	0413	1043
Totalizer4 Weight	USHORT	0215	533	0415	1045
Totalizer4 Unit	USHORT	0216	534	0416	1046
		0217	535	0417	1047
		0217	535	0417	1047
Year Clock	USHORT	0217	535	0417	1047
Clock Month	USHORT	0218	536	0418	1048
Clock Days	USHORT	0219	537	0419	1049
Clock Hour	USHORT	021A	538	041A	1050
Clock Minutes	USHORT	021B	539	041B	1051
Clock Seconds	USHORT	021C	540	041C	1052
QT Q	FLOAT	021D	541	041D	1053
QT unit	USHORT	021F	543	041F	1055
QT Fault	ULONG	0220	544	0420	1056
		0222	546	0422	1058
<b>Pipe / Channel</b>		0222	546	0422	1058
Q	FLOAT	0222	546	0422	1058
Flow unit index	USHORT	0224	548	0424	1060
Average V	FLOAT	0225	549	0425	1061
Average C	FLOAT	0227	551	0427	1063
KH (1)	FLOAT	0229	553	0429	1065
Reynolds (1)	FLOAT	022B	555	042B	1067
Surface	FLOAT	022D	557	042D	1069
Level (2)	FLOAT	022F	559	042F	1071
Height / Channel Description Point (2)	FLOAT	0231	561	0431	1073
Water Height (2)	FLOAT	0233	563	0433	1075
Water Height Max. Delta (2)	FLOAT	0235	565	0435	1077
Fault	ULONG	0237	567	0437	1079
		0239	569	0439	1081

		Pipe/Channel A		Pipe/Channel B	
PARAMETER NAME	Type	JBUS Hex address	JBUS Dec address	JBUS Hex address	JBUS Dec address
<b>chord 01</b>		<b>0239</b>	<b>569</b>	<b>0439</b>	<b>1081</b>
Average V	FLOAT	<b>0239</b>	<b>569</b>	<b>0439</b>	<b>1081</b>
T	FLOAT	<b>023B</b>	<b>571</b>	<b>043B</b>	<b>1083</b>
DeltaT	FLOAT	<b>023D</b>	<b>573</b>	<b>043D</b>	<b>1085</b>
C	FLOAT	<b>023F</b>	<b>575</b>	<b>043F</b>	<b>1087</b>
Gain	FLOAT	<b>0241</b>	<b>577</b>	<b>0441</b>	<b>1089</b>
IQ	FLOAT	<b>0243</b>	<b>579</b>	<b>0443</b>	<b>1091</b>
Fault	ULONG	<b>0245</b>	<b>581</b>	<b>0445</b>	<b>1093</b>
Probe Reference	USHORT	<b>0247</b>	<b>583</b>	<b>0447</b>	<b>1095</b>
Distance Between Probes	USHORT	<b>0248</b>	<b>584</b>	<b>0448</b>	<b>1096</b>
		<b>0249</b>	<b>585</b>	<b>0449</b>	<b>1097</b>
<b>chord 02</b>		<b>0249</b>	<b>585</b>	<b>0449</b>	<b>1097</b>
Average V	FLOAT	<b>0249</b>	<b>585</b>	<b>0449</b>	<b>1097</b>
T	FLOAT	<b>024B</b>	<b>587</b>	<b>044B</b>	<b>1099</b>
DeltaT	FLOAT	<b>024D</b>	<b>589</b>	<b>044D</b>	<b>1101</b>
C	FLOAT	<b>024F</b>	<b>591</b>	<b>044F</b>	<b>1103</b>
Gain	FLOAT	<b>0251</b>	<b>593</b>	<b>0451</b>	<b>1105</b>
IQ	FLOAT	<b>0253</b>	<b>595</b>	<b>0453</b>	<b>1107</b>
Fault	ULONG	<b>0255</b>	<b>597</b>	<b>0455</b>	<b>1109</b>
Probe Reference	USHORT	<b>0257</b>	<b>599</b>	<b>0457</b>	<b>1111</b>
Distance Between Probes	USHORT	<b>0258</b>	<b>600</b>	<b>0458</b>	<b>1112</b>
		<b>0259</b>	<b>601</b>	<b>0459</b>	<b>1113</b>
<b>chord 03</b>		<b>0259</b>	<b>601</b>	<b>0459</b>	<b>1113</b>
Average V	FLOAT	<b>0259</b>	<b>601</b>	<b>0459</b>	<b>1113</b>
T	FLOAT	<b>025B</b>	<b>603</b>	<b>045B</b>	<b>1115</b>
DeltaT	FLOAT	<b>025D</b>	<b>605</b>	<b>045D</b>	<b>1117</b>
C	FLOAT	<b>025F</b>	<b>607</b>	<b>045F</b>	<b>1119</b>
Gain	FLOAT	<b>0261</b>	<b>609</b>	<b>0461</b>	<b>1121</b>
IQ	FLOAT	<b>0263</b>	<b>611</b>	<b>0463</b>	<b>1123</b>
Fault	ULONG	<b>0265</b>	<b>613</b>	<b>0465</b>	<b>1125</b>
Probe Reference	USHORT	<b>0267</b>	<b>615</b>	<b>0467</b>	<b>1127</b>
Distance Between Probes	USHORT	<b>0268</b>	<b>616</b>	<b>0468</b>	<b>1128</b>
		<b>0269</b>	<b>617</b>	<b>0469</b>	<b>1129</b>
<b>chord 04</b>		<b>0269</b>	<b>617</b>	<b>0469</b>	<b>1129</b>
Average V	FLOAT	<b>0269</b>	<b>617</b>	<b>0469</b>	<b>1129</b>
T	FLOAT	<b>026B</b>	<b>619</b>	<b>046B</b>	<b>1131</b>
DeltaT	FLOAT	<b>026D</b>	<b>621</b>	<b>046D</b>	<b>1133</b>
C	FLOAT	<b>026F</b>	<b>623</b>	<b>046F</b>	<b>1135</b>
Gain	FLOAT	<b>0271</b>	<b>625</b>	<b>0471</b>	<b>1137</b>
IQ	FLOAT	<b>0273</b>	<b>627</b>	<b>0473</b>	<b>1139</b>
Fault	ULONG	<b>0275</b>	<b>629</b>	<b>0475</b>	<b>1141</b>
Probe Reference	USHORT	<b>0277</b>	<b>631</b>	<b>0477</b>	<b>1143</b>
Distance Between Probes	USHORT	<b>0278</b>	<b>632</b>	<b>0478</b>	<b>1144</b>
		<b>0279</b>	<b>633</b>	<b>0479</b>	<b>1145</b>

		Pipe/Channel A		Pipe/Channel B	
PARAMETER NAME	Type	JBUS Hex address	JBUS Dec address	JBUS Hex address	JBUS Dec address
<b>Inputs/Outputs</b>		<b>02C9</b>	<b>713</b>	<b>04C9</b>	<b>1225</b>
<b>IO 01A</b>		<b>02C9</b>	<b>713</b>	<b>04C9</b>	<b>1225</b>
Value	FLOAT	<b>02C9</b>	<b>713</b>	<b>04C9</b>	<b>1225</b>
Fault	ULONG	<b>02CB</b>	<b>715</b>	<b>04CB</b>	<b>1227</b>
		<b>02CD</b>	<b>717</b>	<b>04CD</b>	<b>1229</b>
<b>IO 01B</b>		<b>02CD</b>	<b>717</b>	<b>04CD</b>	<b>1229</b>
Value	FLOAT	<b>02CD</b>	<b>717</b>	<b>04CD</b>	<b>1229</b>
Fault	ULONG	<b>02CF</b>	<b>719</b>	<b>04CF</b>	<b>1231</b>
		<b>02D1</b>	<b>721</b>	<b>04D1</b>	<b>1233</b>
<b>IO 02A</b>		<b>02D1</b>	<b>721</b>	<b>04D1</b>	<b>1233</b>
Value	FLOAT	<b>02D1</b>	<b>721</b>	<b>04D1</b>	<b>1233</b>
Fault	ULONG	<b>02D3</b>	<b>723</b>	<b>04D3</b>	<b>1235</b>
		<b>02D5</b>	<b>725</b>	<b>04D5</b>	<b>1237</b>
<b>IO 02B</b>		<b>02D5</b>	<b>725</b>	<b>04D5</b>	<b>1237</b>
Value	FLOAT	<b>02D5</b>	<b>725</b>	<b>04D5</b>	<b>1237</b>
Fault	ULONG	<b>02D7</b>	<b>727</b>	<b>04D7</b>	<b>1239</b>
		<b>02D9</b>	<b>729</b>	<b>04D9</b>	<b>1241</b>
<b>IO 03A</b>		<b>02D9</b>	<b>729</b>	<b>04D9</b>	<b>1241</b>
Value	FLOAT	<b>02D9</b>	<b>729</b>	<b>04D9</b>	<b>1241</b>
Fault	ULONG	<b>02DB</b>	<b>731</b>	<b>04DB</b>	<b>1243</b>
		<b>02DD</b>	<b>733</b>	<b>04DD</b>	<b>1245</b>
<b>IO 03B</b>		<b>02DD</b>	<b>733</b>	<b>04DD</b>	<b>1245</b>
Value	FLOAT	<b>02DD</b>	<b>733</b>	<b>04DD</b>	<b>1245</b>
Fault	ULONG	<b>02DF</b>	<b>735</b>	<b>04DF</b>	<b>1247</b>
		<b>02E1</b>	<b>737</b>	<b>04E1</b>	<b>1249</b>
<b>IO 04A</b>		<b>02E1</b>	<b>737</b>	<b>04E1</b>	<b>1249</b>
Value	FLOAT	<b>02E1</b>	<b>737</b>	<b>04E1</b>	<b>1249</b>
Fault	ULONG	<b>02E3</b>	<b>739</b>	<b>04E3</b>	<b>1251</b>
		<b>02E5</b>	<b>741</b>	<b>04E5</b>	<b>1253</b>
<b>IO 04B</b>		<b>02E5</b>	<b>741</b>	<b>04E5</b>	<b>1253</b>
Value	FLOAT	<b>02E5</b>	<b>741</b>	<b>04E5</b>	<b>1253</b>
Fault	ULONG	<b>02E7</b>	<b>743</b>	<b>04E7</b>	<b>1255</b>
		<b>02E9</b>	<b>745</b>	<b>04E9</b>	<b>1257</b>

		Pipe/Channel A		Pipe/Channel B	
PARAMETER NAME	Type	JBUS Hex address	JBUS Dec address	JBUS Hex address	JBUS Dec address
<b>Function output Start</b>		<b>0319</b>	<b>793</b>	<b>0519</b>	<b>1305</b>
<b>Function output 01</b>		<b>0319</b>	<b>793</b>	<b>0519</b>	<b>1305</b>
Value	FLOAT	<b>0319</b>	<b>793</b>	<b>0519</b>	<b>1305</b>
Fault	ULONG	<b>031B</b>	<b>795</b>	<b>051B</b>	<b>1307</b>
		<b>031D</b>	<b>797</b>	<b>051D</b>	<b>1309</b>
<b>Function output 02</b>		<b>031D</b>	<b>797</b>	<b>051D</b>	<b>1309</b>
Value	FLOAT	<b>031D</b>	<b>797</b>	<b>051D</b>	<b>1309</b>
Fault	ULONG	<b>031F</b>	<b>799</b>	<b>051F</b>	<b>1311</b>
		<b>0321</b>	<b>801</b>	<b>0521</b>	<b>1313</b>
<b>Function output 03</b>		<b>0321</b>	<b>801</b>	<b>0521</b>	<b>1313</b>
Value	FLOAT	<b>0321</b>	<b>801</b>	<b>0521</b>	<b>1313</b>
Fault	ULONG	<b>0323</b>	<b>803</b>	<b>0523</b>	<b>1315</b>
		<b>0325</b>	<b>805</b>	<b>0525</b>	<b>1317</b>
<b>Function output 04</b>		<b>0325</b>	<b>805</b>	<b>0525</b>	<b>1317</b>
Value	FLOAT	<b>0325</b>	<b>805</b>	<b>0525</b>	<b>1317</b>
Fault	ULONG	<b>0327</b>	<b>807</b>	<b>0527</b>	<b>1319</b>
		<b>0329</b>	<b>809</b>	<b>0529</b>	<b>1321</b>
<b>Function output 05</b>		<b>0329</b>	<b>809</b>	<b>0529</b>	<b>1321</b>
Value	FLOAT	<b>0329</b>	<b>809</b>	<b>0529</b>	<b>1321</b>
Fault	ULONG	<b>032B</b>	<b>811</b>	<b>052B</b>	<b>1323</b>
		<b>032D</b>	<b>813</b>	<b>052D</b>	<b>1325</b>
<b>Function output 06</b>		<b>032D</b>	<b>813</b>	<b>052D</b>	<b>1325</b>
Value	FLOAT	<b>032D</b>	<b>813</b>	<b>052D</b>	<b>1325</b>
Fault	ULONG	<b>032F</b>	<b>815</b>	<b>052F</b>	<b>1327</b>
		<b>0331</b>	<b>817</b>	<b>0531</b>	<b>1329</b>
<b>Function output 07</b>		<b>0331</b>	<b>817</b>	<b>0531</b>	<b>1329</b>
Value	FLOAT	<b>0331</b>	<b>817</b>	<b>0531</b>	<b>1329</b>
Fault	ULONG	<b>0333</b>	<b>819</b>	<b>0533</b>	<b>1331</b>
		<b>0335</b>	<b>821</b>	<b>0535</b>	<b>1333</b>
<b>Function output 08</b>		<b>0335</b>	<b>821</b>	<b>0535</b>	<b>1333</b>
Value	FLOAT	<b>0335</b>	<b>821</b>	<b>0535</b>	<b>1333</b>
Fault	ULONG	<b>0337</b>	<b>823</b>	<b>0537</b>	<b>1335</b>
		<b>0339</b>	<b>825</b>	<b>0539</b>	<b>1337</b>
<b>Function output 09</b>		<b>0339</b>	<b>825</b>	<b>0539</b>	<b>1337</b>
Value	FLOAT	<b>0339</b>	<b>825</b>	<b>0539</b>	<b>1337</b>
Fault	ULONG	<b>033B</b>	<b>827</b>	<b>053B</b>	<b>1339</b>
		<b>033D</b>	<b>829</b>	<b>053D</b>	<b>1341</b>
<b>Function output 10</b>		<b>033D</b>	<b>829</b>	<b>053D</b>	<b>1341</b>
Value	FLOAT	<b>033D</b>	<b>829</b>	<b>053D</b>	<b>1341</b>
Fault	ULONG	<b>033F</b>	<b>831</b>	<b>053F</b>	<b>1343</b>

#### IV.4 CRC16 calculation algorithm



$\oplus$  = exclusive OR

n = number of bits

poly = calculation polynomial of CRC16 = 1010 0000 0000 0001 (generator polynomial =  $2 X^2 X^{15} X^{16}$ )

the first byte sent is the one with the least significant bits

# Detailed table of contents

<b>CHAPTER 1: OVERVIEW</b>	<b>4</b>
1.1 Converter overview	5
1.2 Dimensions and weight	5
1.3 Working environment	5
1.4 Protection against dust and immersion	5
1.5 Power supply	6
1.6 Communication	6
1.7 Inputs/Outputs	7
1.8 Ultrasound chords	7
1.9 Navigation keys	7
1.10 Operating lamps	8
1.11 Screen	8
1.12 Functions	9
1.13 Performance of the flow meter	9
1.14 Cleaning the flow meter	9
1.15 Recycling the flow meter	9
1.16 CE marking	10
<b>CHAPTER 2: SAFETY INSTRUCTIONS</b>	<b>11</b>
2.1 Using the flow meter	12
2.2 Symbols used on the flow meter	12
2.3 Contact address	13
<b>CHAPTER 3: INSTALLATION AND WIRING</b>	<b>14</b>
3.1 Wall attachment	15
3.2 Wiring instructions	16
3.3 Connector wiring	16
3.3.1 Communication connector	17
3.3.2 Input/output connectors	19
1) Wiring of the relay modules	20
2) Wiring of the current output modules	20
3) Wiring of the current input modules	20
4) Wiring of the voltage input modules	20
5) Wiring of the temperature modules	21
6) Example of a module configuration	22
7) Plug fitting instructions	23
3.3.3 Probe and chord connector	24
3.3.4 Power supply connector	25
3.4 Ground connection	27
3.5 Connection	27

## CHAPTER 4: INSTALLING A MEASURING POINT \_\_\_\_\_ 28

4.1 Composition of a measuring point _____	29
4.2 Choosing the measurement location _____	29
4.2.1 Straight lengths to be used _____	29
1) Monochord measurement _____	29
2) Multichord measurement _____	31
4.3 Choosing the probe location _____	32
4.4 Installing probes and connectors _____	35
4.4.1. Permanent external (clamp-on) probes _____	35
1) Preparing the pipe _____	35
2) Installing the elastomer strip _____	35
3) Installing the probe _____	35
4.4.2. Temporary external (clamp-on) probes _____	35
1) Preparing the pipe _____	35
2) Selecting and installing the coupling medium _____	35
3) Installing the probe _____	36
4.4.3. Inserted probes _____	36
1) Flanged probes _____	36
2) Screw probes _____	37
3) Probes with air lock _____	37

## CHAPTER 5: USING AND CONFIGURING THE Uf 811 \_\_\_\_\_ 38

5.1 Using the Uf 811 _____	39
5.1.1 Operating mode _____	39
5.1.2 Keypad _____	39
5.2 Main configuration elements _____	40
5.2.1 Number of channels _____	40
5.2.2 Description of the pipe _____	40
5.3 Configuring the Uf 811 _____	40
5.3.1 Flow meter menu ("Settings" mode) _____	41
5.4 SIMPLE configuration _____	42
5.4.1 "Configuration" Menu _____	42
1) "Config. Files" Window _____	42
2) Reinitialisation _____	42
3) Confirmation (of reinitialisation) _____	42
4) Configuration _____	43
5) Menus _____	43
6) Access code _____	43
7) Language _____	43
8) Station name _____	43
9) Back light _____	44
10) Link _____	44
11) Timer before return to "Measurement" mode _____	44
5.4.2 "Pipe/fluid configuration" menu _____	44
1) Number of chords _____	44
2) Flow rate unit (Q unit) _____	44
3) Flow graph _____	44
4) Chord settings _____	45
5) Type of fluid _____	45
6) Definition of the pipe _____	45
5.4.3 "Totalizer configuration" menu (if enabled) _____	46
1) Activation and counting direction _____	46
2) Pulse unit and weight _____	46
3) Resetting a totalizer (if authorised) _____	46
5.4.4 "Inputs/Outputs" menu (if enabled) _____	47
1) Current input and voltage input module _____	47
2) Temperature input module _____	48
3) Contact input module _____	48
4) Current/voltage output module _____	48
5) Relay output module _____	49

5.4.5 "Logger settings" menu (if enabled)	51
1) Resetting the logger	51
2) Confirmation of resetting the logger	51
3) Number of parameters for the logger	51
4) Logger mode	51
5) Logger interval	51
6) Logger autonomy	51
7) Logger variables	52
8) Log on variation	52
5.4.6 "Echo display" menu	53
5.5 NORMAL configuration	54
5.5.1 "Pipe/fluid configuration" menu	54
1) Memory	54
2) Filter	55
3) Delta T0 and Auto zero	56
4) C0 and Delta C	56
5) KH	57
6) Deletion rate (Qeff)	57
5.6 ADVANCED configuration	58
5.6.1 "Pipe/fluid configuration" menu	58
1) Delta V filtering	58
2) Material of the pipe wall	58
3) Laminar/turbulent transition	59
4) Seek gain and Gain max	59
5) Weighting coefficients of the chords	60
5.6.2 "Linearisation settings" menu	60
5.6.3 "Advanced settings" menu	61
1) Simulation mode	61
2) Special probes	61
3) US & TRT processing	61
5.6.4 "Firmware update" menu	61
5.7 "Measurement" mode	62
5.7.1 Pages available	62
1) Flow	62
2) Pipe measurements	62
3) Specific information relating to the chords	62
4) Totalizers	63
5) Date and time	63
6) Info logger	63
7) Events	63
8) Distance between probes	64
9) Flow graph	64
5.7.2 Verification of the quality and consistency of the measurement	64
<b>CHAPTER 6: FUNCTION ENGINE</b>	<b>65</b>
6.1 Principle	66
6.2 Application examples	66
6.2.1 Water temperature calculation	66
6.2.2 Calorimetry	66
<b>CHAPTER 7: PC SOFTWARE</b>	<b>67</b>
7.1 Introduction	68
7.1.1 Installing and running the software	68
7.1.2 Connecting the flow meter to the PC	69
7.1.3 Home page	69
7.1.4 Configuration window	70
7.1.5 Icons	70
7.1.6 File menu	71
7.1.7 Measurement window	71
1) List of available tabs	71
2) "General" tab	72
3) "QA" tab (flow rate)	73
4) "Inputs/outputs" tab	74

7.1.8 Settings window	74
1) List of available tabs	74
2) "General" tab (in the "General" drop-down menu)	75
3) "Logger" tab (in the "General" drop-down menu)	76
4) "Totalizers" tab (in the "General" drop-down menu)	76
5) "Inputs/Outputs" tab (in the "General" drop-down menu)	77
6) "Control" tab (in the "Control" drop-down menu)	78
7) "Chord" tab (in the "Control" drop-down menu)	78
8) "Linearisation" tab (in the "Control" drop-down menu)	79
7.2 Archiving, processing and printing of saved files	80
7.3 Settings files	80
<b>Appendix I: Characteristic echo signals</b>	<b>81</b>
<b>Appendix II: Speed of sound in water</b>	<b>84</b>
<b>Appendix III Troubleshooting</b>	<b>86</b>
III.1 Diagnostic indications	87
III.2 Description of fault bits	89
III.3 Fault grid	92
<b>Appendix IV: Link protocol of the Uf 811</b>	<b>93</b>
IV.1 Serial link characteristics	94
IV.2 Reading of N words (with $N \leq 125$ )	95
IV.3 Modbus / Jbus table	96
IV.4 CRC16 calculation algorithm	100